







GE-CM 36/37 Li-Solo

Item No.: 3413172

Ident No.: 21034

Bar Code: 4006825635898

-CHANGE

The Einhell Cordless Lawn Mower GE-CM 36/37 Li-Solo offers complete cable-free lawn care. PXC batteries can be used in all devices in the system range. Cutting height can be adjusted in six levels from 25-75 mm, the cutting width is 37 cm. The integrated grass comb allows you to cut the grass right up to the edges. The handles are ergonomically designed. The aluminum long handle is lightweight, sturdy, height-adjustable and can be folded. The integrated carry handle makes the unit easy to transport. The 45-I grass basket features a fill level indicator. The high wheeler has wide wheels that protect the lawn. Two 18 V batteries are required for operation. Batteries and charger are available separately, for example as a practical starter set.

Features & Benefits

- Member of the Power X-Change family, 2x18V batteries necessary
- Central cutting height adjustment, 6 levels
- Working without fatigue thanks to ergonomically shaped handle
- Height-adjustable long handle
- Space saving storage thanks to foldable long handle
- Stable and lightweight aluminium-long handle
- 45l grass collection bag with filling indicator
- Integrated carry-handle for easy transport
- Integrated lawn-comb for near edge mowing
- Highwheeler grass protecting, large wheels
- Supplied without battery and charger (available separately)

Technical Data

- Idle speed 3400 min^-1 - Cutting width 37 cm

- Cutting height adjustment 6 | 25-75 mm | central

- Capacity of catching device 45 I - Wheel diameter front 150 mm - Wheel diameter rear 220 mm

Logistic Data

- Gross weight (kg) 19.24 - Product weight (kg) 15.44

- Dimensions single packaging 827 x 469 x 369 mm

- Pieces per export carton 1 Pieces - Gross weight export carton 19.24 kg

- Dimensions export carton 835 x 465 x 370 mm - Container quantity (20"/40"/40"HC) 195 | 398 | 465















36 V **POWER** 2x 18 V



Available as special accessories



Spare Blade GE-CM 36/37+38 Lawn Mower Accessory Item No.: 3405486 Bar Code: 4006825635843





2,0 Ah Power X-Change Battery Item No.: 4511395 Bar Code: 4006825610369

Einhell Accessory



Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory



18V 4,0Ah PXC Starter Kit B1 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory



5,2 Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory



4,0 Ah Power X-Change Battery Item No.: 4511396 Bar Code: 4006825610376 **Einhell Accessory**



18V 2,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512040 Bar Code: 4006825613681 Einhell Accessory

Battery-Running-Times

One Battery for All	lawn mowing ¹
	(m²)
1.5 Ah	200
2.0 Ah	250
2.5 Ah	290
3.0 Ah	400
4.0 Ah	450
5.2 Ah	650
6.0 Ah	800
8.0 Ah	900

Test setup:

1) lawn