



# Einhell

# EXPERT

## POWER X-CHANGE

Robot Lawn Mower

**FREELEXO 450 BT Solo**

**Item No.: 3413944**

Ident No.: 21010

Bar Code: 4006825655148

The Einhell FREELEXO 450 BT SOLO robot lawnmower is a member of the high-performance Power X-Change family which provides unlimited flexibility within the system family. It is controlled via app by Bluetooth and the settings of the robot lawnmower can be set to individual requirements. In addition, it has an intuitive keypad. Using the application the operating time of the Einhell FREELEXO can be precisely programmed for each specific day. The FREELEXO 450 BT SOLO includes everything needed for installation and operation of an Einhell robotic lawnmower of the FREELEXO Series. It is suitable for a lawn area up to 450 m<sup>2</sup>. The scope of delivery includes 140 m wire, 200 fastening hooks, 3 blades and 4 connecting clamps.

## Features & Benefits

- PXC system battery - can also be used for other PXC products
- App using Bluetooth - user-defined robot lawnmower control
- Multi area mowing - for complex gardens
- Intuitive keypad
- Programmable operating time for each specific day
- Safety sensor system thanks to impact, tilt and lift sensors
- Anti-theft protection in form of PIN code and warning signal
- Rain sensor
- Cutting height adjustment (20-60mm)
- Suitable for slopes up to 35%
- Carry-handle for comfortable transport
- Automatic return to charging unit and charging
- Lawn areas up to 450 m<sup>2</sup>
- Wire 125 m
- Fastening hooks 180 pcs.
- Blades 3 pcs.
- Connecting clamps 4 pcs.



## Technical Data

- |                             |                       |
|-----------------------------|-----------------------|
| - Power                     | 18 V                  |
| - Accumulator               | 18 V   0 mAh   Li-Ion |
| - Cutting width             | 18 cm                 |
| - Slope                     | 35 %                  |
| - Cutting height adjustment | Continuously 20-60 mm |
| - Recommended area          | 450 m <sup>2</sup>    |
| - Perimeter wire            | 125 m                 |
| - Hooks                     | 180 Pieces            |
| - Spare blades              | Yes, three pieces     |
| - Connecting clamps         | 4 Pieces              |

## Logistic Data

- |  |                    |
|--|--------------------|
| - Product weight (kg)                  | 14.3               |
| - Gross weight (kg)                    | 15.8               |
| - Dimensions single packaging          | 723 x 512 x 318 mm |
| - Pieces per export carton             | 1 Pieces           |
| - Gross weight of export carton        | 15.8 kg            |
| - Dimensions export carton             | 737 x 530 x 327 mm |
| - Container quantities (20"/40"/40"HC) | 224   462   528    |



## Available as special accessories



Power X-Boostcharger 6A  
Charger  
Item No.: 4512064  
Bar Code: 4006825629019  
Einhell Accessory



18V 3,0Ah Power X-Change Plus  
Battery  
Item No.: 4511501  
Bar Code: 4006825644197  
Einhell Accessory



18V 2,5Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512097  
Bar Code: 4006825646962  
Einhell Accessory



Installation Kit 800m2  
Robot Lawn Mower Accessory  
Item No.: 3414011  
Bar Code: 4006825646870  
Einhell Accessory



2x 3,0Ah & 30min PXC Kit  
PXC-Starter-Kit  
Item No.: 4512098  
Bar Code: 4006825646986  
Einhell Accessory



18V 4,0Ah Power X-Change  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



18V 4,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



Begrenzungsdraht 50 m  
Robot Lawn Mower Accessory  
Item No.: 3414021  
Bar Code: 4006825648782  
Einhell Accessory



Befestigungshaken 100 Stk  
Robot Lawn Mower Accessory  
Item No.: 3414023  
Bar Code: 4006825648805  
Einhell Accessory



Power X-Fastcharger 4A  
Charger  
Item No.: 4512103  
Bar Code: 4006825650228  
Einhell Accessory



2x 18V 4,0Ah PXC-Twinpack  
Battery  
Item No.: 4511489  
Bar Code: 4006825638578  
Einhell Accessory



Power X-Twincharger 3A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



18V Battery Charger 3,0A - PXC  
Charger  
Item No.: 4514095  
Bar Code: 4006825655292  
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack  
Battery  
Item No.: 4511526  
Bar Code: 4006825656695  
Einhell Accessory



2x 3,0Ah & Twincharger Kit  
PXC-Starter-Kit  
Item No.: 4512083  
Bar Code: 4006825638509  
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus  
Battery  
Item No.: 4511502  
Bar Code: 4006825644210  
Einhell Accessory



Installation Kit 500m2  
Robot Lawn Mower Accessory  
Item No.: 3414010  
Bar Code: 4006825646863  
Einhell Accessory



Installation Kit 1200m2  
Robot Lawn Mower Accessory  
Item No.: 3414012  
Bar Code: 4006825646887  
Einhell Accessory



18V 2,0Ah Power X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



18V 3,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512041  
Bar Code: 4006825613698  
Einhell Accessory



Ersatzklingen 12 Stk  
Robot Lawn Mower Accessory  
Item No.: 3414020  
Bar Code: 4006825648775  
Einhell Accessory



Verbindungsklemmen 4 Stk  
Robot Lawn Mower Accessory  
Item No.: 3414022  
Bar Code: 4006825648799  
Einhell Accessory



18V 2,5Ah Power X-Change  
Battery  
Item No.: 4511516  
Bar Code: 4006825650518  
Einhell Accessory



18V 5,2Ah Power X-Change Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack  
Battery  
Item No.: 4511518  
Bar Code: 4006825651676  
Einhell Accessory



Mähroboter Garage  
Robot Lawn Mower Accessory  
Item No.: 3414024  
Bar Code: 4006825654417  
Einhell Accessory

2x 18V 2,5Ah PXC-Twinpack CB  
Battery  
Item No.: 4511524  
Bar Code: 4006825656206  
Einhell Accessory