



# Einhell

## EXPERT



Cordless Grass- and Bush Shear  
**GE-CG 18/100 Li T (1x 2,5Ah)**

Item No.: 3410316

Ident No.: 21014

Bar Code: 4006825680829

The Einhell GE-CG 18/100 Li T (1x 2,5 Ah) cordless grass and shrub shears are a powerful member of the smart Power X-Change family. The grass cutting blade (100 mm) is ideal for lawn edges, while the laser-cut and diamond-ground shrub shear blades (200 mm) are perfect for trimming bushes and hedges. The blades can be exchanged without tools. In use, the Softgrip provides perfect handling and ergonomics. The covered gearbox housing protects against accidental contact with transmission oil. Included in the scope of delivery are a telescopic extension for particularly ergonomic application as well as a 2.5 Ah Power X-Change battery and a charging device.

## Features & Benefits




- Member of the Power X-Change family, 1x 18 V battery required
- Grass cutting blade, perfect for caring for lawn edges
- Shrub shear blade for hedge and bush care
- Easy and tool-free blade change
- Laser-cut and diamond-ground blades
- Includes telescopic extension for particularly ergonomic use
- Extension handle with 5 tilt positions
- Covered transmission housing protects against contact with transmission oil
- Softgrip provides optimal grip and ergonomics
- Delivery with 2.5 Ah Power X-Change battery and charging device

## Technical Data

- Cutting width with grass shear knife 100 mm
- Cutting length with shrub cutting knife 200 mm
- Cutting thickness with shrub cutting knife 8 mm
- Spacing between teeth of shrub cutting knife 8 mm
- Accumulator 18 V | 2500 mAh | Li-Ion
- Number of accumulators 1 Pieces

## Logistic Data

- Product weight 0 kg
- Gross weight single packaging 3.9 kg
- Dimensions single packaging 191 x 136 x 935 mm
- Pieces per export carton 4 Pieces
- Gross weight export carton 15.6 kg
- Dimensions export carton 950 x 400 x 288 mm
- Container quantity (20"/40"/40"HC) 1040 | 2144 | 2440



## Available as special accessories



4-6 Ah Multi-Ah Power X-Change Plus Battery  
Item No.: 4511502  
Bar Code: 4006825644210  
Einhell Accessory



4,0 Ah Power X-Change Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



2x2 Power X-Quattrocharger 4A Charger  
Item No.: 4512102  
Bar Code: 4006825649536  
Einhell Accessory



2x 5,2Ah & Twincharger Kit PXC-Starter-Kit  
Item No.: 4512108  
Bar Code: 4006825652376  
Einhell Accessory



18V 3,0 Ah Power-X-Change 1 Battery  
Item No.: 4511341  
Bar Code: 4006825590593  
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1 PXC-Starter-Kit  
Item No.: 4512112  
Bar Code: 4006825655766  
Einhell Accessory



5,2Ah & 4A Fastcharger PXC-Starter-Kit  
Item No.: 4512114  
Bar Code: 4006825656787  
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB A1 Battery  
Item No.: 4511489  
Bar Code: 4006825638578  
Einhell Accessory



18V 4-6Ah & 6A Boostcharger PXC-Starter-Kit  
Item No.: 4512143  
Bar Code: 4006825667653  
Einhell Accessory



5,2 Ah Power X-Change Plus Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



18V 4,0Ah SEALED PXC Plus A1 Battery  
Item No.: 4511627  
Bar Code: 4006825673227  
Einhell Accessory



18V 3Ah PXC Plus Twinpack Battery  
Item No.: 4511631  
Bar Code: 4006825673692  
Einhell Accessory



18V Battery Charger 3,0A - PXC Charger  
Item No.: 4514095  
Bar Code: 4006825655292  
Einhell Accessory



3,0 Ah Power X-Change Plus Battery  
Item No.: 4511501  
Bar Code: 4006825644197  
Einhell Accessory



18V 2,5Ah PXC Starter Kit PXC-Starter-Kit  
Item No.: 4512097  
Bar Code: 4006825646962  
Einhell Accessory



18V 4,0Ah PXC Starter Kit A1 PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



Power X-Fastcharger 4A Charger  
Item No.: 4512103  
Bar Code: 4006825650228  
Einhell Accessory



Power X-Twincharger 3A Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



Power X-Car Charger 3A Charger  
Item No.: 4512113  
Bar Code: 4006825655377  
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack Battery  
Item No.: 4511526  
Bar Code: 4006825656695  
Einhell Accessory



PXC Battery Mounting Gadget PXC-Battery Accessory  
Item No.: 4514155  
Bar Code: 4006825658774  
Einhell Accessory



18V 5-8Ah Multi-Ah PXC Plus Battery  
Item No.: 4511600  
Bar Code: 4006825665055  
Einhell Accessory



Power X-Boostcharger 8A Charger  
Item No.: 4512155  
Bar Code: 4006825670554  
Einhell Accessory



18V 4,0Ah Power-X-Change Plus Battery  
Item No.: 4511553  
Bar Code: 4006825660869  
Einhell Accessory



18V 4Ah PXC Plus Twinpack Battery  
Item No.: 4511629  
Bar Code: 4006825673685  
Einhell Accessory



2,0 Ah Power X-Change Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



18V 3,0Ah SEALED PXC Plus A1 Battery  
Item No.: 4511618  
Bar Code: 4006825672794  
Einhell Accessory

# Battery-Running-Times



trimming<sup>1</sup>  
(min.)

One Battery for All

1.5 Ah	180
2.0 Ah	240
2.5 Ah	300
3.0 Ah	360
4.0 Ah	480
5.2 Ah	650
6.0 Ah	720
8.0 Ah	960

Test setup:

1) lawn