



# Einhell

# EXPERT

## POWER X-CHANGE

Cordless Drill

**TE-CD 18/2 Li +39 (1x2,5 Ah)**

**Item No.: 4514219**

Ident No.: 21033

Bar Code: 4006825661811

The Einhell TE-CD 18/2 Li +39 (1x2.5 Ah) cordless drill/driver is a member of the PXC family and offers cordless freedom for jobs in the home, workshop and garage. For both powerful screw driving or drilling, the 2-speed cordless drill/driver has a quick-change chuck with Quick Stop function and enables fast tool change thanks to the automatic spindle lock. The torque slip coupling allows sensitive operation and the ergonomic Softgrip enables comfortable operation, even on long work sessions there is an LED light for illuminating the work area. The product is supplied complete with the belt clip, 1 x 2.5Ah PXC rechargeable battery with Fastcharger, plus the comprehensive 39 piece bit set and the practical E-Box.

## Features & Benefits

- Member of the Power X-Change family
- 2-speed gearing for powerful screwing and fast drilling
- Single-sleeve quick change drill chuck
- Automatic spindle lock for easy tool change
- Overload slip coupling prevents over-turning of screws
- Ergonomic soft grip for comfortable operation
- Incl. LED to illuminate the work area
- Incl. practical belt clip
- Incl. 1 x 2,5 Ah rechargeable PXC batteries and Fastcharger
- Delivered in the practical transport and storage case E-Box
- Supplied with an extensive 39 pieces bit and drill set



## Technical Data

- Accumulator	18 V   2500 mAh   Li-Ion
- Charging time	50min
- Number of gears	2
- Idle speed (gear 1)	0-350 min <sup>-1</sup>
- Idle speed (gear 2)	0-1250 min <sup>-1</sup>
- Max. torque hard	44 Nm
- Number of torque steps	21 settings
- Drill chuck	10 mm   single sleeve
- Number of accumulators	1 Pieces



## Logistic Data

- Product weight	1.01 kg
- Gross weight single packaging	3.36 kg
- Dimensions single packaging	350 x 340 x 100 mm
- Pieces per export carton	4 Pieces
- Gross weight export carton	15.3 kg
- Dimensions export carton	430 x 365 x 360 mm
- Container quantity (20"/40"/40"HC)	1960   3964   4812



## Available as special accessories



4-6 Ah Multi-Ah Power X-Change Plus Battery  
Item No.: 4511502  
Bar Code: 4006825644210



4,0 Ah Power X-Change Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



2x2 Power X-Quattrocharger 4A Charger  
Item No.: 4512102  
Bar Code: 4006825649536  
Einhell Accessory



2x 5,2Ah & Twincharger Kit PXC-Starter-Kit  
Item No.: 4512108  
Bar Code: 4006825652376  
Einhell Accessory



18V 3,0 Ah Power-X-Change 1 Battery  
Item No.: 4511341  
Bar Code: 4006825590593  
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1 PXC-Starter-Kit  
Item No.: 4512112  
Bar Code: 4006825655766  
Einhell Accessory



5,2Ah & 4A Fastcharger PXC-Starter-Kit  
Item No.: 4512114  
Bar Code: 4006825656787  
Einhell Accessory



3,0 Ah Power X-Change Plus Battery  
Item No.: 4511501  
Bar Code: 4006825644197  
Einhell Accessory



18V 5-8Ah Multi-Ah PXC Plus Battery  
Item No.: 4511600  
Bar Code: 4006825665055  
Einhell Accessory



Handy Bitbox Impact 12tlg. Akku-Bohrschrauber-Zubehör  
Item No.: 49155025  
Bar Code: 4009311550255  
Einhell Accessory



Bitsatz 34 tlg. S-Box Akku-Bohrschrauber-Zubehör  
Item No.: 49108801  
Bar Code: 4009311088017  
Einhell Accessory



Bit-Bohrerbox 39tlg. L-Box Akku-Bohrschrauber-Zubehör  
Item No.: 49108956  
Bar Code: 4009311089564  
Einhell Accessory



5,2 Ah Power X-Change Plus Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



18V 4Ah PXC Plus Twinpack Battery  
Item No.: 4511629  
Bar Code: 4006825673685  
Einhell Accessory



18V 2,5Ah PXC Starter Kit PXC-Starter-Kit  
Item No.: 4512097  
Bar Code: 4006825646962  
Einhell Accessory



18V 4,0Ah PXC Starter Kit A1 PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



Power X-Fastcharger 4A Charger  
Item No.: 4512103  
Bar Code: 4006825650228  
Einhell Accessory



Power X-Twincharger 3A Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



Power X-Car Charger 3A Charger  
Item No.: 4512113  
Bar Code: 4006825655377  
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack Battery  
Item No.: 4511526  
Bar Code: 4006825656695  
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB A1 Battery  
Item No.: 4511489  
Bar Code: 4006825638578



Power X-Caravan Charger 3A Charger  
Item No.: 4512136  
Bar Code: 4006825664010  
Einhell Accessory



18V 4-6Ah & 6A Boostcharger PXC-Starter-Kit  
Item No.: 4512143  
Bar Code: 4006825667653  
Einhell Accessory



Bit-Bohrerbox 22tlg. S-Box Akku-Bohrschrauber-Zubehör  
Item No.: 49108806  
Bar Code: 4009311088062  
Einhell Accessory



Power X-Boostcharger 8A Charger  
Item No.: 4512155  
Bar Code: 4006825670554  
Einhell Accessory



18V 4,0Ah Power-X-Change Plus Battery  
Item No.: 4511553  
Bar Code: 4006825660869  
Einhell Accessory



18V 3Ah PXC Plus Twinpack Battery  
Item No.: 4511631  
Bar Code: 4006825673692  
Einhell Accessory



18V 2.0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512040  
Bar Code: 4006825613681  
Einhell Accessory




2,0 Ah Power X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



18V Battery Charger 3,0A - PXC  
Charger  
Item No.: 4514095  
Bar Code: 4006825655292  
Einhell Accessory

## Battery-Running-Times

One Battery for All	 screwing <sup>1</sup> (pieces)
1.5 Ah	180
2.0 Ah	240
2.5 Ah	300
3.0 Ah	360
4.0 Ah	480
5.2 Ah	625
6.0 Ah	720
8.0 Ah	960

**Test setup:**

1) screws - 6x60 mm