



Einhell

EXPERT

POWER X-CHANGE

Robot Lawn Mower

FREELEXO 500 LCD BT+

Item No.: 3413982

Ident No.: 21010

Bar Code: 4006825655131

The Robot Lawn Mower FREELEXO 500 LCD BT+ is part of the Power X-Change family, so the 2.5 Ah lithium ion battery pack is fully compatible with all units in the PXC range. FREELEXO can be controlled via Bluetooth using the dedicated app and an intuitive keypad with LCD display. Mowing times can be programmed for each day and a separate program started for secondary areas. The multi-zone/spot lawn mower is also equipped with cutting height adjustment from 20-60 mm, PIN coded anti-theft protection, and sensors to help it cope with rain, impact, tilt and lift on slopes of up to 35%. In ECO mode, the mower automatically returns to the charging station when required. The unit comes with installation equipment for a lawn size of 500 m².


Features & Benefits

- PXC system battery - can also be used for other PXC products
- App control using Bluetooth-user-defined robot lawnmower control
- Intuitive keypad with LCD display
- Programmable operating time for each specific day
- Safety sensor system thanks to impact, tilt and lift sensors
- PIN code anti-theft protection
- Rain sensor
- ECO mode for the charging station
- Multizone mowing - for complex gardens
- Spot mowing
- Mowing program for border areas
- Cutting height adjustment facility (20-60mm)
- Suitable for inclines up to 35%
- Automatic return to charging unit and charging
- Incl. installation equipment for 500 m² lawns
- Incl. 2.5 Ah PXC rechargeable battery
- 130 m perimeter wire
- 190 fastening hooks
- 3 spare blades
- 4 connecting clamps



Technical Data

- Power	18 V
- Battery	18 V 2500 mAh Li-Ion
- Cutting width	18 cm
- Slope	35 %
- Cutting height adjustment	20 mm - 60 mm
- Recommended area	500 m ²
- Perimeter wire	130 m
- Hooks	190 Pieces
- Spare blades	3
- Connecting clamps	4 Pieces



Logistic Data

- Product weight (kg)	13.5
- Gross weight (kg)	16.5
- Dimensions single packaging	692 x 437 x 313 mm
- Pieces per export carton	1 Pieces
- Gross weight of export carton	18.5 kg
- Dimensions export carton	700 x 440 x 315 mm
- Container quantities (20"/40"/40"HC)	294 602 688

Available as special accessories



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



2x 3,0Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512083
Bar Code: 4006825638509
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



Installation Kit 500m2
Robot Lawn Mower Accessory
Item No.: 3414010
Bar Code: 4006825646863
Einhell Accessory



Installation Kit 800m2
Robot Lawn Mower Accessory
Item No.: 3414011
Bar Code: 4006825646870
Einhell Accessory



Installation Kit 1200m2
Robot Lawn Mower Accessory
Item No.: 3414012
Bar Code: 4006825646887
Einhell Accessory



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



Spare blades 12 psc
Robot Lawn Mower Accessory
Item No.: 3414020
Bar Code: 4006825648775
Einhell Accessory



Perimeter wire 50 m
Robot Lawn Mower Accessory
Item No.: 3414021
Bar Code: 4006825648782
Einhell Accessory



Connecting clamps 4 psc
Robot Lawn Mower Accessory
Item No.: 3414022
Bar Code: 4006825648799
Einhell Accessory



Fastening hook 100 psc
Robot Lawn Mower Accessory
Item No.: 3414023
Bar Code: 4006825648805
Einhell Accessory



12V 2,0Ah Li-Battery
Battery
Item No.: 4511472
Bar Code: 4006825634655
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



18V 2,5Ah Power X-Change
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



2x 5,2Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



robot lawn mower garage
Robot Lawn Mower Accessory
Item No.: 3414024
Bar Code: 4006825654417
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack CB
Battery
Item No.: 4511524
Bar Code: 4006825656206
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



5,2Ah & 4A Fastcharger
PXC-Starter-Kit
Item No.: 4512114
Bar Code: 4006825656787
Einhell Accessory



Cleaning Kit
Robot Lawn Mower Accessory
Item No.: 3414025
Bar Code: 4006825657951
Einhell Accessory



Repair Kit
Robot Lawn Mower Accessory
Item No.: 3414026
Bar Code: 4006825657968
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 2
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory



18V 4,0Ah PXC Starter Kit 2
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



2x 4,0Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



18V 4,0Ah Power-X-Change Plus
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



18V 4,0Ah Power X-Change 2
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 3,0 Ah Power-X-Change 2
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory