



# Einhell

## EXPERT

### POWER X-CHANGE

Cordless Lawn Mower

**GE-CM 36/34 Li-Solo**

**Item No.: 3413191**

Ident No.: 11018

Bar Code: 4006825637588

The Einhell Cordless Lawn Mower GE-CM 36/34 Li-Solo offers complete freedom from cables when looking after your lawn. PXC batteries can be used in all the devices in this successful system range from Einhell. The cutting height can be adjusted to five levels from 25 to 65 mm. The handles are ergonomically designed. The aluminum long handle is lightweight, sturdy, height-adjustable and can be folded for practical, easy storage. The integrated carry handle makes the unit easy to transport. The grass basket has a capacity of 30 liters and comes with a filling level indicator. Two 18 V batteries are required for operation. PXC batteries and charger are available separately, for example as a practical starter set.

## Features & Benefits


- Member of the Power X-Change family, 2x18V batteries necessary
- Central cutting height adjustment, 5 levels
- Working without fatigue thanks to ergonomically shaped handle
- Height-adjustable long handle
- Space saving storage thanks to foldable long handle
- Stable and lightweight aluminium-long handle
- Integrated carry-handle for easy transport
- Filling level indication from the grass collection box
- Wide wheels with lawn-friendly running surface
- Supplied without battery and charger (available separately)

## Technical Data

- Idle speed	3400 min <sup>-1</sup>
- Cutting width	33.5 cm
- Cutting height adjustment	5 settings   25-65 mm   central
- Capacity of catching device	30 L
- Wheel diameter front	150 mm
- Wheel diameter rear	180 mm

## Logistic Data

- Product weight	11.75 kg
- Gross weight single packaging	15.44 kg
- Dimensions single packaging	760 x 440 x 380 mm
- Pieces per export carton	1 Pieces
- Gross weight export carton	16 kg
- Dimensions export carton	760 x 440 x 380 mm
- Container quantity (20"/40"/40"HC)	234   468   546



## Available as special accessories



Ersatzmesser GE-CM 33 Li+36/34  
Lawn Mower Accessory  
Item No.: 3405452  
Bar Code: 4006825610611  
Einhell Grey



18V 2,0 Ah Power-X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



18V 2,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512040  
Bar Code: 4006825613681  
Einhell Accessory



18V 4,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



18V 30min Power-X-Change  
Charger  
Item No.: 4512011  
Bar Code: 4006825587029  
Einhell Accessory



Power-X-Boostcharger 6 A  
Charger  
Item No.: 4512064  
Bar Code: 4006825629019  
Einhell Accessory



18V 1,5Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512021  
Bar Code: 4006825601350  
Einhell Accessory



18V 4,0 Ah Power-X-Change  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



18V 3,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512041  
Bar Code: 4006825613698  
Einhell Accessory



18V 2,6Ah P-X-C Plus  
Battery  
Item No.: 4511436  
Bar Code: 4006825616590  
Einhell Accessory



18V 5,2 Ah P-X-C Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



Power-X-Twincharger 3 A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory