







Einhell






FREELEXO CAM PLUS






1






2




3



4




5



1
ON

2




3



4



6



1
PIN: 0-0-0-0
(0 → OK)

SET




BACK



MODE



START



3



2x







4



2

5

7



CHECK



1

PIN: 0-0-0-0
(0 → OK)

SET



BACK



3



MODE




START



2


4



8

1

PIN: 0-0-0-0
(0 → OK)



SET



BACK



4



MODE



START



2

5

