



# Einhell

# EXPERT

## POWER X-CHANGE

### Cordless Ratchet Wrench

### TE-RW 18/60 Li-Solo

Item No.: 4514320

Ident No.: 21014

Bar Code: 4006825680621

The Einhell cordless ratchet wrench TE-RW 18/60 Li-Solo is the perfect addition to any workshop and is part of the Power X-Change family. The ratchet wrench is compact in design and suitable for working on narrow points. With its 3/8" tool holder and a torque of 60 Nm, the ratchet wrench can loosen and tighten even more tightly fitted screws. Switching from clockwise to counterclockwise is easy with a switch. Using the speed electronics, it is possible to work according to the application. The LED light ensures perfect illumination of the working area. The scope of delivery includes an adapter to a 1/2" tool holder. Battery and charging device not included.

## Features & Benefits

- Member of the Power X-Change family, 1 x 18 V battery required
- Compact device, ideal for automotive applications
- Can also be used as a hand ratchet
- Robust 3/8-inch external square chuck
- High torque for tightening and loosening screws and nuts
- Easy switching for clockwise/counterclockwise rotation
- Stepless speed electronics for application-orientated work
- Ergonomic design with softgrip inserts for comfortable operation
- Large switch for different grip positions
- LED light for optimal illumination of the work area
- Incl. Adapter from 3/8" to 1/2" tool chuck
- Delivered without battery or charging device (available separately)




## Technical Data

- Idle speed 260 min<sup>-1</sup>
- Max. Torque 60 Nm
- Tool collet (square) 0.38 Inch

## Logistic Data

- Product weight (kg) 0.82
- Gross weight (kg) 1.3
- Dimensions single packaging 373 x 93 x 93 mm
- Pieces per export carton 8 Pieces
- Gross weight of export carton 10.8 kg
- Dimensions export carton 391 x 384 x 202 mm
- Containermengen (20"/40"/40"HC) 6880 | 14800 | 17160



## Available as special accessories



5,2 Ah Power X-Change Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



PXC+ 18V 5-8Ah MULTI  
Battery  
Item No.: 4511600  
Bar Code: 4006825665055  
Einhell Accessory



PXC+ 18V 4,0Ah SEALED  
Battery  
Item No.: 4511627  
Bar Code: 4006825673227  
Einhell Accessory



PXC+ 18V 4,0Ah  
Battery  
Item No.: 4511553  
Bar Code: 4006825660869  
Einhell Accessory



PXC+ 18V 3,0Ah SEALED  
Battery  
Item No.: 4511618  
Bar Code: 4006825672794  
Einhell Accessory



PXC 18V 3,0Ah  
Battery  
Item No.: 4511341  
Bar Code: 4006825590593  
Einhell Accessory



3,0 Ah Power X-Change Plus  
Battery  
Item No.: 4511501  
Bar Code: 4006825644197  
Einhell Accessory



2,0 Ah Power X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



4,0 Ah Power X-Change  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change  
Plus  
Battery  
Item No.: 4511502  
Bar Code: 4006825644210



2x 18V 5,2Ah PXC-Twinpack  
Battery  
Item No.: 4511526  
Bar Code: 4006825656695  
Einhell Accessory



18V 4Ah PXC Plus Twinpack  
Battery  
Item No.: 4511629  
Bar Code: 4006825673685  
Einhell Accessory



18V 3Ah PXC Plus Twinpack  
Battery  
Item No.: 4511631  
Bar Code: 4006825673692  
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB  
B1  
Battery  
Item No.: 4511489  
Bar Code: 4006825638578



2x2 Power X-Quattrocharger 4A  
Charger  
Item No.: 4512102  
Bar Code: 4006825649536  
Einhell Accessory



Power X-Fastcharger 4A  
Charger  
Item No.: 4512103  
Bar Code: 4006825650228  
Einhell Accessory



Power X-Twincharger 3A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



Power X-Car Charger 3A  
Charger  
Item No.: 4512113  
Bar Code: 4006825655377  
Einhell Accessory



18V 2,5Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512097  
Bar Code: 4006825646962  
Einhell Accessory



18V 4,0Ah PXC Starter Kit A1  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1  
PXC-Starter-Kit  
Item No.: 4512112  
Bar Code: 4006825655766  
Einhell Accessory



18V 4-6Ah & 6A Boostcharger  
PXC-Starter-Kit  
Item No.: 4512143  
Bar Code: 4006825667653  
Einhell Accessory



18V 2,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512040  
Bar Code: 4006825613681  
Einhell Accessory



E-Case L with wheels  
System Carrying Case  
Item No.: 4540014  
Bar Code: 4006825660562  
Einhell Accessory



E-Case S-F  
System Carrying Case  
Item No.: 4540011  
Bar Code: 4006825653991  
Einhell Accessory



E-Case M  
System Carrying Case  
Item No.: 4540021  
Bar Code: 4006825667721  
Einhell Accessory

# Battery-Running-Times

<b>One Battery for All</b>	fastening and releasing <sup>1</sup> (null)
<b>1.5 Ah</b>	155
<b>2.0 Ah</b>	305
<b>2.5 Ah</b>	385
<b>3.0 Ah</b>	460
<b>4.0 Ah</b>	610
<b>5.2 Ah</b>	790
<b>6.0 Ah</b>	920
<b>8.0 Ah</b>	1220

**Test setup:**

1) -