



# Einhell

# CLASSIC



Cordless Fan

**GC-CF 18/110 Li-Solo**

**Item No.: 3408061**

Ident No.: 21013

Bar Code: 4006825677645

The Einhell cordless fan GC-CF 18/110 Li brings fresh air. The tool is driven by a brushless motor for enhanced power and longer runtimes. Once you register online, the brushless motor has a 10-year guarantee. The portable cordless fan is designed for both outdoor and indoor use. Thanks to its clamp, the fan can be securely attached to, for example, tables or pipes, etc. Additionally, the fan can be moved along two axes: at the lower axis, the cordless fan can rotate 300° in both directions, while it can tilt up to 290° at the fan head. Delivery without battery and charger (available separately).

## Features & Benefits

- Member of the Power X-Change family, 1x 18V battery required
- Brushless motor - more power and longer running time
- Brushless - 10-year motor warranty after registration
- Compact cordless fan for indoor & outdoor use
- Continuous adjustment of the fan head
- Mounting hooks for individual suspension
- Practical carrying handle for mobile use
- 3 level adjustment of the air flow
- Supplied without battery and charger (sold separately)



## Technical Data

- Wind speed 15 km/h
- Fan diameter 11 cm

## Logistic Data

- Product weight (kg) 0.476
- Gross weight (kg) 0.847
- Dimensions single packaging 181 x 94 x 265 mm
- Pieces per export carton 10 Pieces
- Gross weight of export carton 9.1 kg
- Dimensions export carton 485 x 380 x 280 mm
- Container quantity (20"/40"/40"HC) 5760 | 11520 | 12960



## Available as special accessories



PXC Battery Mounting Gadget  
PXC-Battery Accessory  
Item No.: 4514155  
Bar Code: 4006825658774  
Einhell Accessory



5,2 Ah Power X-Change Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



PXC+ 18V 5-8Ah MULTI  
Battery  
Item No.: 4511600  
Bar Code: 4006825665055  
Einhell Accessory



PXC+ 18V 4,0Ah SEALED  
Battery  
Item No.: 4511627  
Bar Code: 4006825673227  
Einhell Accessory



PXC+ 18V 4,0Ah  
Battery  
Item No.: 4511553  
Bar Code: 4006825660869  
Einhell Accessory



PXC+ 18V 3,0Ah SEALED  
Battery  
Item No.: 4511618  
Bar Code: 4006825672794  
Einhell Accessory



PXC 18V 3,0Ah  
Battery  
Item No.: 4511341  
Bar Code: 4006825590593  
Einhell Accessory



3,0 Ah Power X-Change Plus  
Battery  
Item No.: 4511501  
Bar Code: 4006825644197  
Einhell Accessory



2,0 Ah Power X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



4,0 Ah Power X-Change  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change  
Plus  
Battery  
Item No.: 4511502  
Bar Code: 4006825644210



2x 18V 5,2Ah PXC-Twinpack  
Battery  
Item No.: 4511526  
Bar Code: 4006825656695  
Einhell Accessory



18V 4Ah PXC Plus Twinpack  
Battery  
Item No.: 4511629  
Bar Code: 4006825673685  
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB  
B1  
Battery  
Item No.: 4511489  
Bar Code: 4006825638578



2x2 Power X-Quattrocharger 4A  
Charger  
Item No.: 4512102  
Bar Code: 4006825649536  
Einhell Accessory



Power X-Fastcharger 4A  
Charger  
Item No.: 4512103  
Bar Code: 4006825650228  
Einhell Accessory



Power X-Twincharger 3A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



Power X-Car Charger 3A  
Charger  
Item No.: 4512113  
Bar Code: 4006825655377  
Einhell Accessory



Power X-Boostcharger 8A  
Charger  
Item No.: 4512155  
Bar Code: 4006825670554  
Einhell Accessory



18V Battery Charger 3,0A - PXC  
Charger  
Item No.: 4514095  
Bar Code: 4006825655292  
Einhell Accessory



18V 2,5Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512097  
Bar Code: 4006825646962  
Einhell Accessory



18V 4,0Ah PXC Starter Kit A1  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1  
PXC-Starter-Kit  
Item No.: 4512112  
Bar Code: 4006825655766  
Einhell Accessory



18V 4-6Ah & 6A Boostcharger  
PXC-Starter-Kit  
Item No.: 4512143  
Bar Code: 4006825667653  
Einhell Accessory





E-Case L with wheels  
System Carrying Case  
Item No.: 4540014  
Bar Code: 4006825660562  
Einhell Accessory



E-Case M  
System Carrying Case  
Item No.: 4540021  
Bar Code: 4006825667721  
Einhell Accessory

# Battery-Running-Times

One Battery for All	 running time <sup>1</sup> (h)	 running time <sup>2</sup> (h)
1.5 Ah	4	19.5
2.0 Ah	5.3	26
2.5 Ah	6.6	32
3.0 Ah	8	38.5
4.0 Ah	11	51
5.2 Ah	14	67
6.0 Ah	16	77
8.0 Ah	21.2	102

**Test setup:**

1) Max. electronic speed

2) Min. electronic speed