



Einhell

CLASSIC



Cordless Lawn Trimmer
GC-CT 18/24 Li P-Solo
Item No.: 3411104

Ident No.: 11018

Bar Code: 4006825635690

The Einhell GC-CT 18/24 Li P-Solo cordless grass trimmer is the ideal helper for bringing the garden and strips of grass into shape. The cordless grass trimmer is a member of the Power X-Change family. The powerful system batteries are used in all tools across the series. 1 x 18 V battery is required for operation. For comfortable working without fatigue there is an additional handle for two-handed operation. The housing and the secondary handle are made of impact-proof, high-grade plastic. The cutting width is 24 cm with a speed of 8,500 rpm. The product is supplied complete with 20 plastic blades. The system battery and charger are available separately.

Features & Benefits

- Member of the Power-X-Change family, 1x18V batteries necessary
- Fatigue-free and agile operation thanks to low weight
- User-friendly two-hand operation thanks to additional handle
- Housing and handle made of impact-resistant, high-grade plastic
- Incl. 20 plastic blades
- Supplied without battery and charger (available separately)

Technical Data

- Revolutions of knife 8500 rpm
- Cutting width of knife 24 cm
- Number of accumulators 0 Pieces

Logistic Data

- Product weight 1.2 kg
- Gross weight single packaging 1.86 kg
- Dimensions single packaging 180 x 150 x 490 mm
- Pieces per export carton 8 Pieces
- Gross weight export carton 14.94 kg
- Dimensions export carton 635 x 505 x 390 mm



ADDITIONAL HANDLE




EASY HANDLING



INCL. 20 pcs BLADES



1 x 18V BATTERY POWERED (NOT INCLUDED)



Available as special accessories



Spare Blade-set PXC Trimmer
Lawn Trimmer Accessory
Item No.: 3405730
Bar Code: 4006825560404
Einhell Grey



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0Ah Power X-Change 1
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory

Battery-Running-Times

One Battery for All	 trimming ¹ (min.)
1.5 Ah	40
2.0 Ah	55
2.5 Ah	65
3.0 Ah	80
4.0 Ah	125
5.2 Ah	160
6.0 Ah	180
8.0 Ah	250

Test setup:

1) lawn