



Einhell

EXPERT



Cordl.Handstick Vacuum Cleaner

TE-SV 18 Li-FLX-Solo

Item No.: 2347189

Ident No.: 21015

Bar Code: 4006825688481

The Einhell TE-SV 18 Li-FLX-Solo cordless stick vacuum cleaner is part of the Power X-Change cordless platform. Thanks to its 3-in-1 function, this cordless device can be used flexibly as a handheld or stick vacuum cleaner with a flexible swivel joint. Its motorised floor nozzle with joint and LED lighting ensures thorough cleaning on both hard floors and carpets. The suction tube features a flexible joint for easy access under furniture. Two power settings provide optimal suction performance. The bagless dust container can be emptied at the touch of a button, while the triple filtration system with cyclone separator ensures clean exhaust air. Supplied with a wall mount and practical accessories. Battery and charger are sold separately.

Features & Benefits

- Member of the Power XChange family, 1 x 18 V battery required
- Cordless operation thanks to interchangeable battery system
- Can also be used flexibly as a handheld vacuum cleaner
- Flex joint tube for hard-to-reach areas
- Bagless dust container with one-touch emptying
- Triple filter system incl. washable pleated filter
- Always-on function for convenient handling
- Two power modes for optimal suction
- Spotlight LEDs on floor nozzle for better visibility
- Includes 1 x motorised combo floor nozzle
- Includes 1 x 2-in-1 nozzle
- Includes 1 x flexible crevice nozzle
- Includes wall mount with accessory storage
- Supplied without battery and charger




Technical Data

- | | |
|----------------------|--------|
| - Voltage | 18 V |
| - Dirt bag size | 0.6 L |
| - Motor brush width | 225 mm |
| - Brush roller width | 170 mm |

Logistic Data

- | | |
|--|--------------------|
| - Product weight (kg) | 1.05 |
| - Gross weight (kg) | 3.55 |
| - Dimensions single packaging | 245 x 176 x 775 mm |
| - Pieces per export carton | 1 Pieces |
| - Gross weight of export carton | 3.55 kg |
| - Container quantities (20"/40"/40"HC) | 893 1832 1974 |




EXCHANGEABLE BATTERY PACK




ALWAYS-ON FUNCTION



3 IN 1




FLEXIBLE CREVICE NOZZLE



PXC BATTERY
BATTERY & CHARGER
NOT INCLUDED



18 V



120
mbar
SUCTION
POWER



CYCLON

Available as special accessories



Replacement brush
Handstick Vacuum Cleaner Acc.
Item No.: 2351265
Bar Code: 4006825661569
Einhell Accessory



washable filter
Handstick Vacuum Cleaner Acc.
Item No.: 2351266
Bar Code: 4006825661576
Einhell Accessory



Accessory set with hose
Handstick Vacuum Cleaner Acc.
Item No.: 2351267
Bar Code: 4006825665017
Einhell Accessory



PXC 18V 5,2Ah
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



PXC+ 18V 3,0Ah
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory




PXC 18V 2,0Ah
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



PXC 18V 4,0Ah
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



PXC+ 18V 4-6Ah MULTI
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



Power X-Twincharger 4A
Charger
Item No.: 4512161
Bar Code: 4006825680638
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory





18V 4,0Ah PXC Starter Kit C1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



4Ah PLUS PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512159
Bar Code: 4006825680331
Einhell Accessory

Battery-Running-Times

One Battery for All		
	running time ¹ (min.)	running time ² (min.)
1.5 Ah	19	8
2.0 Ah	25	11
2.5 Ah	31	13
3.0 Ah	38	18
4.0 Ah	50	22
5.2 Ah	65	28
6.0 Ah	80	35
8.0 Ah	100	44

Test setup:

- 1) ECO
- 2) BOOST