



# Einhell

**EXPERT Plus**

**POWER X CHANGE**

## TE-JS 18 Li Kit (1x2,0Ah)

### Cordless Jig Saw

Item No.: 4321203

Ident No.: 11015

Bar Code: 4006825613803

The Einhell TE-JS 18 Li Kit (1x2.0Ah) cordless jigsaw offers maximum precision coupled with easy handling. Thanks to the smooth operation, this tool even handles awkward precision work. The dust blower function and an LED light for illuminating the cutting area ensure that the user has a safe view. The integrated plastic sliding element protects sensitive workpieces, while the chip guard enables cuts without splintering. The additional attachable cutting line guide and the selectable pendulum action enable cutting work to be performed quickly and easily. The universal blade holder without tools enables easy changeovers. This product comes with a 2.0 Ah Power X-Change battery and a Power X-Change high-speed charger.

### Features

- Member of the Power X-Change family
- Very smooth operation for exact cutting
- Selectable pendulum action for fast cutting
- Universal blade holder without tools
- Includes dust blow-off function for optimum visibility
- LED light to illuminate the cutting area
- Integrated plastic sliding element for sensitive workpieces
- Additional attachable cutting line guide for exact cutting
- Complete with chip guard for cuts without splintering
- Includes 2,0Ah Power X-Change battery and highspeed charger




### Technical Data

- Accumulator	18 V   2000 mAh   Li-Ion
- Charging time	40min
- Mains supply of battery charger	200-260 V   50-60 Hz
- Number of strokes	2400 min <sup>-1</sup>
- Stroke height	25.4 mm
- Cutting depth in wood	80 mm
- Cutting depth in plastic	12 mm
- Cutting depth in steel	10 mm
- Max. bevel cuts	47 °
- Toolless saw blade change	yes
- Number of accumulators	1 Pieces

### Logistic Data

- Product weight	1.82 kg
- Gross weight single packaging	3.18 kg
- Dimensions single packaging	255 x 155 x 226 mm
- Pieces per export carton	4 Pieces
- Gross weight export carton	16.2 kg
- Container quantity (20"/40"/40"HC)	2240   4640   5440



## Available as special accessories



18V 5,2 Ah Power-X-Change  
Battery  
Item No.: 4511357  
Bar Code: 4006825598865  
Einhell Accessory



18V 30min Power-X-Change  
Power Tools Accessory  
Item No.: 4512011  
Bar Code: 4006825587029  
Einhell Accessory



18V Starter-Kit Power-X-Change  
PXC-Starter-Kit  
Item No.: 4512021  
Bar Code: 4006825601350  
Einhell Accessory



18V 1,5 Ah Power-X-Change  
Battery  
Item No.: 4511340  
Bar Code: 4006825590586  
Einhell Accessory



18V 3,0 Ah Power-X-Change  
Battery  
Item No.: 4511341  
Bar Code: 4006825590593  
Einhell Accessory