



Einhell

CLASSIC



Cordless Leaf Blower

GC-CL 18/1 Li E-Solo

Item No.: 3433541

Ident No.: 21021

Bar Code: 4006825651645

The GC-CL 18/1 Li E-Solo cordless universal blower is ideal for blowing leaves, grass clippings and other dirt and debris from courtyards, driveways, footpaths, garages, terraces and outdoor furniture. The handy size and low weight enable very user-friendly operation. The split tube allows for easy cleaning of outdoor furniture in confined spaces while the full-length tube makes quick work of paths and driveways. Thanks to the detachable tube the storage of the blower is also space-saving. Additionally the electronic speed control allows the user to vary the air speed to suit the application while the soft grip handle provides added comfort during use.

This product comes without a battery and without charger which are available separately.

Features & Benefits

- Low weight and easy handling
- 2-parts tube for universal operation around house and garden
- Electronic speed control
- Softgrip for user-friendly operation
- Strong blow velocity with 210 km/h
- Supplied without battery and charger (available separately)



Technical Data

- No-load speed (idle speed) 12000 min⁻¹
- Blow velocity 210 km/h
- Max. air volume 105 m³/h

Logistic Data

- Product weight 1.33 kg
- Gross weight single packaging 1.91 kg
- Dimensions single packaging 490 x 155 x 182 mm
- Pieces per export carton 8 Pieces
- Gross weight export carton 15.62 kg
- Dimensions export carton 635 x 505 x 385 mm
- Container quantity (20"/40"/40"HC) 1600 | 3280 | 3936



Available as special accessories



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



2x 3,0Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512083
Bar Code: 4006825638509
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0Ah Power X-Change 1
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 2,5Ah Power X-Change
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory





Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory

Battery-Running-Times

One Battery for All	 blowing ¹	 blowing ²
	(min.)	(min.)
1.5 Ah	180	10
2.0 Ah	240	14
2.5 Ah	300	16
3.0 Ah	390	20
4.0 Ah	480	26
5.2 Ah	660	40
6.0 Ah	720	42

Test setup:

1) Min. electronic speed

2) Max. electronic speed