



Einhell

CLASSIC



Cordless Fan

GC-CF 18/110 Li-Solo

Item No.: 3408061

Ident No.: 21013

Bar Code: 4006825677645

The Einhell cordless fan GC-CF 18/110 Li brings fresh air. The tool is driven by a PurePOWER brushless motor for enhanced power and longer runtimes. Once you register online, the brushless motor has a 10-year guarantee. The portable cordless fan is designed for both outdoor and indoor use. Thanks to its clamp, the fan can be securely attached to, for example, tables or pipes, etc. Additionally, the fan can be moved along two axes: at the lower axis, the cordless fan can rotate 300° in both directions, while it can tilt up to 290° at the fan head. Delivery without battery and charger (available separately).

Features & Benefits

- Member of the Power X-Change family, 1x 18V battery required
- Brushless motor - more power and longer running time
- PurePOWER Brushless - 10-year motor warranty after registration
- Compact cordless fan for indoor & outdoor use
- Continuous adjustment of the fan head
- Mounting hooks for individual suspension
- Practical carrying handle for mobile use
- 3 level adjustment of the air flow
- Supplied without battery and charger (sold separately)



Technical Data

- Wind speed 15 km/h
- Fan diameter 11 cm

Logistic Data

- Product weight (kg) 0.482
- Gross weight (kg) 1.04
- Dimensions single packaging 183 x 92 x 260 mm
- Pieces per export carton 10 Pieces
- Gross weight of export carton 7.5 kg
- Dimensions export carton 485 x 380 x 280 mm
- Container quantity (20"/40"/40"HC) 5520 | 11330 | 12590



Available as special accessories



4-6 Ah Multi-Ah Power X-Change Plus Battery
Item No.: 4511502
Bar Code: 4006825644210



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



4,0 Ah Power X-Change Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 4,0Ah PXC Starter Kit A1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



2x2 Power X-Quattrocharger 4A Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



2x 5,2Ah & Twincharger Kit PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory



Power X-Twincharger 3A Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



18V 3,0 Ah Power-X-Change 1 Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



Power X-Car Charger 3A Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1 PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



PXC Battery Mounting Gadget PXC-Battery Accessory
Item No.: 4514155
Bar Code: 4006825658774
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB A1 Battery
Item No.: 4511489
Bar Code: 4006825638578



18V 4-6Ah & 6A Boostcharger PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



Power X-Boostcharger 8A Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



5,2 Ah Power X-Change Plus Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



PXC+ 18V 5-8Ah MULTI Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



18V 4,0Ah Power-X-Change Plus Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



18V 4,0Ah SEALED PXC Plus A1 Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



18V 4Ah PXC Plus Twinpack Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



2,0 Ah Power X-Change Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V Battery Charger 3,0A - PXC Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory





18V 3,0Ah SEALED PXC Plus A1 Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



3,0 Ah Power X-Change Plus Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory

Battery-Running-Times

One Battery for All	 running time ¹ (h)	 running time ² (h)
1.5 Ah	4	19.5
2.0 Ah	5.3	26
2.5 Ah	6.6	32
3.0 Ah	8	38.5
4.0 Ah	11	51
5.2 Ah	14	67
6.0 Ah	16	77
8.0 Ah	21.2	102

Test setup:

1) Max. electronic speed

2) Min. electronic speed