



Einhell

EXPERT

POWER X-CHANGE

Robot Lawn Mower

FREELEXO 300 Solo

Item No.: 3413961

Ident No.: 21010

Bar Code: 4006825655018

The Robot Lawn Mower FREELEXO 300 Solo is part of the high-performance Power X-Change family. It has an intuitive keypad and comes with cutting height adjustment from 20-60 mm and a PIN code controlled anti-theft protection system, as well as rain, impact, tilt and lift sensors that enable the unit to cope with slopes of up to 35%. Not only can the mowing times be programmed in 8 stages, but it is also possible to run a separate program for mowing additional areas that are not part of the main lawn. Charging is initiated automatically when battery power gets low. The unit is supplied with the necessary installation equipment for a lawn size of 300 m² (100 m boundary wire, 140x fastening hooks, 3x replacement blades, 4x connecting clips).



Features & Benefits

- PXC system battery - can also be used for other PXC products
- Intuitive keypad
- Programmable operating time with 8 settings
- Safety sensor system thanks to impact, tilt and lift sensors
- PIN code anti-theft protection
- Rain sensor
- Cutting height adjustment facility (20-60mm)
- Suitable for inclines up to 35%
- Mowing program for border areas
- Automatic return to charging unit and charging
- Incl. installation equipment for 300 m² lawns
- Supplied without battery or charger (available separately)
- 100 m perimeter wire
- 140 fastening hooks
- 3 spare blades
- 4 connecting clamps



Technical Data


- | | |
|-----------------------------|-----------------------|
| - Power | 18 V |
| - Battery | 18 V 0 mAh Li-Ion |
| - Cutting width | 18 cm |
| - Slope | 35 % |
| - Cutting height adjustment | 20 mm - 60 mm |
| - Recommended area | 300 m ² |
| - Perimeter wire | 100 m |
| - Hooks | 140 Pieces |
| - Spare blades | Yes, three pieces |
| - Connecting clamps | 4 Pieces |



FREELEXO

Logistic Data

- | | |
|--|--------------------|
| - Product weight (kg) | 11 |
| - Gross weight (kg) | 16.4 |
| - Dimensions single packaging | 690 x 430 x 305 mm |
| - Pieces per export carton | 1 Pieces |
| - Gross weight of export carton | 16.4 kg |
| - Dimensions export carton | 700 x 440 x 315 mm |
| - Container quantities (20"/40"/40"HC) | 294 602 688 |



Available as special accessories



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



Installation Kit 800m2
Robot Lawn Mower Accessory
Item No.: 3414011
Bar Code: 4006825646870
Einhell Accessory



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



Ersatzklingen 12 Stk
Robot Lawn Mower Accessory
Item No.: 3414020
Bar Code: 4006825648775
Einhell Accessory



Verbindungsklemmen 4 Stk
Robot Lawn Mower Accessory
Item No.: 3414022
Bar Code: 4006825648799
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



Reparaturset
Robot Lawn Mower Accessory
Item No.: 3414026
Bar Code: 4006825657968
Einhell Accessory

18V 4,0Ah PXC Starter Kit 2
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



2x 3,0Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512083
Bar Code: 4006825638509
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



Installation Kit 500m2
Robot Lawn Mower Accessory
Item No.: 3414010
Bar Code: 4006825646863
Einhell Accessory



Installation Kit 1200m2
Robot Lawn Mower Accessory
Item No.: 3414012
Bar Code: 4006825646887
Einhell Accessory



18V 4,0Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



Begrenzungsdraht 50 m
Robot Lawn Mower Accessory
Item No.: 3414021
Bar Code: 4006825648782
Einhell Accessory



Befestigungshaken 100 Stk
Robot Lawn Mower Accessory
Item No.: 3414023
Bar Code: 4006825648805
Einhell Accessory



18V 2,5Ah Power X-Change
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Mähroboter Garage
Robot Lawn Mower Accessory
Item No.: 3414024
Bar Code: 4006825654417
Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack CB
Battery
Item No.: 4511524
Bar Code: 4006825656206
Einhell Accessory



Cleaning Set
Robot Lawn Mower Accessory
Item No.: 3414025
Bar Code: 4006825657951
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory