



Einhell

CLASSIC



Cordless Drill

TC-CD 18/35 Li (1x2,0 Ah)

Item No.: 4514229

Ident No.: 21023

Bar Code: 4006825673906

The Einhell Cordless Drill/Driver TC-CD 18/35 Li (1x2.0 Ah) is a popular aid for any job. With a torque of up to 35 Nm, 21 torque levels and a drilling setting, the speed electronics allow the tool to be adapted to the material and task at hand. The chuck (10 mm) accepts the desired tool accessory in no time at all. For optimal working even in dark areas, the LEDs ensure perfect illumination of the work area. The ergonomic design and Softgrip surfaces enable comfortable operation. The set includes a 2.0 Ah Power X-Change battery and a charger.

Features & Benefits


- Part of the Power X-Change family
- Speed electronics to adapt to the material and application
- Always ready for use thanks to Li-ion technology without self-discharge
- Easy to work in dark areas thanks to LED illumination
- Really handy thanks to ergonomic design and Softgrip
- Incl. 1 x 2.0 Ah Power X-Change battery and cradle charger
- Supplied in a practical storage box

Technical Data

- | | |
|--------------------------|--------------------------|
| - Accumulator | 18 V 2000 mAh Li-Ion |
| - Charging time | 2,5h |
| - Number of gears | 1 |
| - Idle speed (gear 1) | 0-550 min ⁻¹ |
| - Max. torque hard | 35 Nm |
| - Number of torque steps | 21+1 settings |
| - Drill chuck | 10 mm double sleeve |
| - Number of accumulators | 1 Pieces |

Logistic Data

- | | |
|--------------------------------------|--------------------|
| - Product weight | 1.39 kg |
| - Gross weight single packaging | 2.07 kg |
| - Dimensions single packaging | 241 x 104 x 206 mm |
| - Pieces per export carton | 4 Pieces |
| - Gross weight export carton | 14.82 kg |
| - Dimensions export carton | 440 x 258 x 226 mm |
| - Container quantity (20"/40"/40"HC) | 4304 |



Available as special accessories



4-6 Ah Multi-Ah Power X-Change Plus Battery
Item No.: 4511502
Bar Code: 4006825644210



4,0 Ah Power X-Change Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



Power X-Fastcharger 4A Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Twincharger 3A Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Car Charger 3A Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



3,0 Ah Power X-Change Plus Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



18V 4-6Ah & 6A Boostcharger PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



18V 4,0Ah Power-X-Change Plus Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



18V 4,0Ah SEALED PXC Plus A1 Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



18V 3Ah PXC Plus Twinpack Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



2,0 Ah Power X-Change Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB B1 Battery
Item No.: 4511489
Bar Code: 4006825638578



18V 2,5Ah PXC Starter Kit PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x2 Power X-Quattrocharger 4A Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



2x 5,2Ah & Twincharger Kit PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory



18V 3,0 Ah Power-X-Change 1 Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1 PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



5,2Ah & 4A Fastcharger PXC-Starter-Kit
Item No.: 4512114
Bar Code: 4006825656787
Einhell Accessory



18V 5-8Ah Multi-Ah PXC Plus Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



5,2 Ah Power X-Change Plus Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



18V 3,0Ah SEALED PXC Plus A2 Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



18V 4Ah PXC Plus Twinpack Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



18V 2,0Ah PXC Starter Kit PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 4,0Ah PXC Starter Kit B1 PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory

Battery-Running-Times



screwing¹
(pieces)

One Battery for All

1.5 Ah	220
2.0 Ah	295
2.5 Ah	366
3.0 Ah	440
4.0 Ah	590
5.2 Ah	760
6.0 Ah	880
8.0 Ah	1180

Test setup:

1) wood - 6x60 mm