







**GE-CF 18/2200 Li - Solo** 

Item No.: 3408035

Ident No.: 21011

Bar Code: 4006825665253

WER CHANGE

The Einhell cordless fan GE-CF 18/2200 Li is a breath of fresh air. The cordless device can be used anywhere, ensuring air supply or distribution of air flows. The fan is a member of the Power X-Change family. The battery can be used in more than 200 Einhell devices. Compact and portable, the cordless fan is intended for both outdoor and indoor use. The adjustment on the fan head is infinitely variable. Thanks to numerous fastening options, use is universal. There are three stages for adjusting the air flow. Up to 18 hours of battery life possible with a 5.2 Ah PXC battery. Delivery does not include battery or charger (sold separately).

### Features & Benefits

- A member of the Power X-Change family, 1x 18V batteries required
- Compact, portable cordless fan for indoor and outdoor use
- Infinitely variable adjustment of the fan head
- Universal use thanks to numerous fastening options
- 3 settings for adjusting the air flow
- Runs for up to 18 hours with one 5.2 Ah PXC battery
- Supplied without a battery and charger (available separately)

## **Technical Data**

2200 - 1200 min^-1 - No-load speed - Wind speed 15000 m/h - Fan diameter 180 mm - Swiveling range 0 - 360°

# **Logistic Data**

- Product weight (kg) 1.19 - Gross weight (kg) 1.79

- Dimensions single packaging 285 x 225 x 215 mm

- Pieces per export carton 6 Pieces - Gross weight of export carton 11.4 kg

- Dimensions export carton 700 x 295 x 455 mm - Container quantity (20"/40"/40"HC) 1860 | 3900 | 4224



















## Available as special accessories



5,2 Ah Power X-Change Plus

Battery Item No.: 4511437

Bar Code: 4006825616606

Einhell Accessory



PXC+ 18V 4,0Ah Battery Item No.: 4511553

Bar Code: 4006825660869

**Einhell Accessory** 



3,0 Ah Power X-Change Plus

Battery

Item No.: 4511501

Bar Code: 4006825644197

**Einhell Accessory** 



4,0 Ah Power X-Change

Battery Item No.: 4511396

Bar Code: 4006825610376

**Einhell Accessory** 



2x 18V 5,2Ah PXC-Twinpack

Battery

Item No.: 4511526

Bar Code: 4006825656695 Einhell Accessory



2x2 Power X-Quattrocharger 4A

Charger Item No.: 4512102 Bar Code: 4006825649536

Einhell Accessory



Power X-Twincharger 3A Charger Item No.: 4512069

Bar Code: 4006825629729

Einhell Accessory



18V 2,0Ah PXC Starter Kit PXC-Starter-Kit

Item No.: 4512040 Bar Code: 4006825613681

Einhell Accessory



E-Case M

System Carrying Case Item No.: 4540021

Bar Code: 4006825667721

Einhell Accessory



PXC+ 18V 5-8Ah MULTI

Battery Item No.: 4511600

Bar Code: 4006825665055

Einhell Accessory



PXC 18V 3,0Ah Battery Item No.: 4511341

Bar Code: 4006825590593 Einhell Accessory



2,0 Ah Power X-Change

Battery

Item No.: 4511395

Bar Code: 4006825610369

**Einhell Accessory** 



4-6 Ah Multi-Ah Power X-Change

Battery

Item No.: 4511502 Bar Code: 4006825644210



2x18V 4,0Ah PXC-Twinpack CB

Battery Item No.: 4511489 Bar Code: 4006825638578



Power X-Fastcharger 4A

Charger Item No.: 4512103 Bar Code: 4006825650228

Einhell Accessory



Power X-Car Charger 3A

Charger Item No.: 4512113

Bar Code: 4006825655377 Einhell Accessory



E-Case L with wheels System Carrying Case Item No.: 4540014 Bar Code: 4006825660562

Einhell Accessory

# **Battery-Running-Times**

	-=⊘	<b>-≡⊘</b>
One Battery for All	blowing <sup>1</sup>	blowing <sup>2</sup>
	(h)	(h)
1.5 Ah	5.3	2
2.0 Ah	7	2.6
2.5 Ah	8.8	3.3
3.0 Ah	10.6	4
4.0 Ah	14	5.6
5.2 Ah	18.3	7
6.0 Ah	21.2	8
8.0 Ah	28	10.6

<sup>1)</sup> Min. electronic speed