



Spend a little Live a lot

Great care has gone into the manufacture of this product and it should therefore provide you with years of good service when used properly. In the event of product failure within its intended use over the course of the first 3 years after date of purchase, we will remedy the problem as quickly as possible once it has been brought to our attention. In the unlikely event of such an occurrence, or if you require any information about the product, please contact us via our helpline support services, details of which are to be found both in this manual and on the product itself.

If you are not entirely satisfied with this product, please return it to the store where it was purchased and we will be pleased to replace or refund it. This does not affect your statutory rights.



PRODUCED IN CHINA FOR:

ALDI STORES LTD., PO BOX 26, ATHERSTONE, WARWICKSHIRE, CV9 2SH.

ALDI STORES (IRELAND) LTD.  
PO BOX 726, NAAS, CO. KILDARE.  
Visit us at [www.aldi.com](http://www.aldi.com)

AFTER SALES SUPPORT

☎ 0151 649 1500  
☎ 1890 94 62 44 [www.einhell.co.uk](http://www.einhell.co.uk)

MODEL: WZDS 75 K PRODUCT CODE: 77014 ON-SALE DATE: 07/2017



Spend a little Live a lot

# User Manual



## 75W DETAIL SANDER Plus 14 piece Accessory Set



Original instruction manual

## Contents

<b>Pack contents/parts</b> .....	<b>3-4</b>
<b>General information</b> .....	<b>5</b>
Reading and storing the original instruction manual.....	6
Explanation of symbols.....	6
Use and storage of the user guide.....	7
Proper Use.....	8
Reasonably foreseeable misuse.....	9
<b>Safety</b> .....	<b>10</b>
Explanation of the symbols and types of instructions used.....	10
Explanation of the pictograms for handling on the machine.....	11
Safety devices.....	12
Safety instructions.....	13-28
<b>Set up</b> .....	<b>29-35</b>
<b>Use</b> .....	<b>36-39</b>
Description of the components and control elements.....	36
Operation.....	36-38
Safety.....	39
Malfunction and remedy (FAQ).....	39
<b>Cleaning</b> .....	<b>40-41</b>
<b>Maintenance and servicing</b> .....	<b>42-43</b>
Maintenance and Storage.....	42-43
Storage and transport.....	43-44
Ordering replacement parts.....	44
Replacing the power cable.....	45
<b>Technical data</b> .....	<b>46-49</b>
Declaration of conformity.....	49
<b>Warranty</b> .....	<b>50-52</b>
<b>Recycling</b> .....	<b>53</b>



**Manufacturer's information:**  
 Einhell UK Ltd, Unit 9, Stadium Court, Wirral International Business Park,  
 Plantation Road, Bromborough, CH62 3QG

**AFTER SALES SUPPORT**

www.einhell.co.uk 0151 649 1500 1890 94 62 44

MODEL: **WZDS 75 K** PRODUCT CODE: **77014** ON-SALE DATE: **07/2017**


**3**  
 YEAR  
 WARRANTY

**Pack contents/parts**

- 1 ON/OFF (BUTTON) switch
- 2 75W Detail Sander
- 3 Dust collection box
- 4 Oscillating plate
- 5 Sanding sheet (peel-off)
- 6 Finger sanding attachment
- 7 Screw – Finger sanding attachment (As supplied fitted into the oscillating plate)
- 8 Sanding finger piece (peel-off)
- 9 Storage bag
- 10 Polishing pad (peel off)
- 11 Rust removing pad (peel off)
- 12 13A plug and supply cable
- 13 Original operating & safety instructions
- 14 Handle

**Recycling**

The unit is supplied in packaging to prevent it being damaged in transit. This packaging is raw material and can therefore be reused or can be returned to the raw material stream.



**The packaging material is partly recyclable.** Dispose of the packaging in an environmentally friendly way adding to your recyclable waste bin, or by taking it to a public collection centre.

The unit and its accessories are made of various types of material, such as metal and plastic. Defective components must be disposed of as special waste. Ask your dealer or your local council.



**For EU countries only**

Never place any electric tools in your household refuse.

To comply with European Directive 2012/19/EU concerning old electric and electronic equipment and its implementation in national laws, old electric tools have to be separated from other waste and disposed of in an environment-friendly fashion, e.g. by taking to a recycling depot.

Recycling alternative to the demand to return electrical devices: As an alternative to returning the electrical device, the owner is obliged to cooperate in ensuring that the device is properly recycled if ownership is relinquished. This can also be done by handing over the used device to a returns centre, which will dispose of it in accordance with national commercial and industrial waste management legislation. This does not apply to the accessories and auxiliary equipment which are included with the used device.

The reprinting or reproduction by any other means, in whole or in part, of documentation and papers accompanying products is permitted only with the express consent of Einhell UK Ltd.