



Einhell

EXPERT

POWER X-CHANGE

Robot Lawn Mower

FREELEXO CAM PLUS 600

Item No.: 3413975


Ident No.: 21024

Bar Code: 4006825678413

The Einhell FREELEXO CAM PLUS 600 is part of the Power X-Change family, which can be combined with each other. Using an integrated camera and sensors, the FREELEXO CAM PLUS 600 can identify the boundaries of the lawn to be mowed by detecting lawns based on colours and structures. In addition, areas can be quickly excluded using magnetic tape. In addition, it is equipped with WiFi for connection to the Einhell Connect app as well as an LCD display and a keypad for programming on the device. The robotic lawn mower is designed for areas of up to 600 m². The scope of delivery includes a 4.0 Ah Power X-Change Plus battery, a charging station and suitable installation equipment.



Features & Benefits

- Member of the Power X-Change family, 1 x 18V battery required
- Brushless motor - more power and longer running time
- Robot mower recognises mowing area thanks to integrated camera
- Individual robotic lawn mower control via app
- Intuitive keypad and LED display
- Programmable mowing times
- Return to the charging station and automatic charging process
- Safety sensors thanks to impact, tilt and lift sensors
- Integrated rain sensor
- Theft protection via PIN code
- Cutting height adjustment: 20 - 60 mm
- Suitable for slopes up to 25%
- Incl. 5 m magnetic tape for short-term boundaries in the garden
- Carrying handle for convenient transport
- Lawn areas up to 600 m²
- 25x fastening hooks
- 2x connecting clamps and 3x replacement blades
- Incl. 1x 4.0 Ah Power X-Change Plus battery and charging station



Technical Data

- Power	18 V
- Accumulator	18 V 4000 mAh Li-Ion
- Cutting width	18 cm
- Slope	25 %
- Cutting height adjustment	20 mm - 60 mm
- Recommended area	600 m ²
- Perimeter wire	0.12 m
- Guide wire	12 m
- Hooks	25 Pieces
- Spare blades	3
- Connecting clamps	2 Pieces



Logistic Data

- Product weight (kg)	9.5
- Gross weight (kg)	16.74
- Dimensions single packaging	695 x 440 x 315 mm
- Pieces per export carton	1 Pieces
- Gross weight of export carton	16.74 kg
- Dimensions export carton	700 x 445 x 325 mm
- Container quantities (20"/40"/40"HC)	294 602 688

Available as special accessories



Spare blades 12 psc
Robot Lawn Mower Accessory
Item No.: 3414020
Bar Code: 4006825648775
Einhell Accessory



Connecting clamps 4 psc
Robot Lawn Mower Accessory
Item No.: 3414022
Bar Code: 4006825648799
Einhell Accessory



robot lawn mower garage
Robot Lawn Mower Accessory
Item No.: 3414024
Bar Code: 4006825654417
Einhell Accessory



Repair Kit
Robot Lawn Mower Accessory
Item No.: 3414026
Bar Code: 4006825657968
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



Perimeter wire 50 m
Robot Lawn Mower Accessory
Item No.: 3414021
Bar Code: 4006825648782
Einhell Accessory



Fastening hook 100 psc
Robot Lawn Mower Accessory
Item No.: 3414023
Bar Code: 4006825648805
Einhell Accessory



Cleaning Kit
Robot Lawn Mower Accessory
Item No.: 3414025
Bar Code: 4006825657951
Einhell Accessory



5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory