



Einhell

EXPERT

POWER X-CHANGE

Cordless Hedge Trimmer

GE-CH 36/65 Li-Solo

Item No.: 3410960

Ident No.: 21034

Bar Code: 4006825639018

The Einhell GE-CH 36/65 Li-Solo cordless hedge trimmer is a powerful tool which operates without a cable thanks to Power X-Change. The hedge trimmer for cutting through hedges, shrubs and bushes is powered by two 18 V PXC rechargeable batteries. The cutters are made of laser-cut and diamond-ground steel and just like the metal gear unit, are designed for a long life. The rotating handle and ergonomic, slimline front handle with microswitch make it comfortable to work with. The cordless hedge trimmer has an aluminium cover for the cutters. The product is supplied complete with a practical cuttings collector, impact guard with wall holder and a sturdy cutter guard for storage and transport. The battery and charger are available separately.

Features & Benefits

- Member of the Power X-Change family, 2x18V batteries necessary
- Blades made of laser-cut and diamond-ground steel
- Swivel handle
- Ergonomic, small front handle with micro switches
- Metal gearing for a long life
- Cutting collector
- Aluminium cover over cutters
- Shock guard with holder for wall mount
- Sturdy cutter guard for storage and transportation
- Supplied without battery and charger (available separately)



Technical Data

- Cutting length 650 mm
- Blade length 720 mm
- Spacing between teeth 30 mm
- Cuts per minute 2700 min⁻¹

Logistic Data

- Product weight 4 kg
- Gross weight single packaging 5.6 kg
- Dimensions single packaging 1172 x 230 x 203 mm
- Pieces per export carton 4 Pieces
- Gross weight export carton 23.14 kg
- Dimensions Export Carton 1200 x 485 x 290 mm
- Container quantity (20"/40"/40"HC) 532 | 1176 | 1344



DIAMOND GRINDED KNIFE / LASERCUT KNIFE



ADJUSTABLE HANDLE



CUTTING COLLECTOR




WALL HOLDER




2x 18 V BATTERIES POWERED (NOT INCLUDED)




BATTERY & CHARGER NOT INCLUDED



36 V POWER 2 x 18 V



30 mm



650 mm

Available as special accessories



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 4,0Ah PXC Starter Kit A1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Maintenance spray
Hedge Trimmer Accessory
Item No.: 3403099
Bar Code: 4006825654608
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
A1
Battery
Item No.: 4511489
Bar Code: 4006825638578

Power X-Caravan Charger 3A
Charger
Item No.: 4512136
Bar Code: 4006825664010
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



5,2 Ah PXC Starter-Kit
PXC-Starter-Kit
Item No.: 4512147
Bar Code: 4006825675153
Einhell Accessory



4Ah PLUS PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512159
Bar Code: 4006825680331
Einhell Accessory



PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory




4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210

Battery-Running-Times

| One Battery for All |  running time ¹ (min.) |
|---------------------|--|
| 1.5 Ah | 60 |
| 2.0 Ah | 75 |
| 2.5 Ah | 93 |
| 3.0 Ah | 120 |
| 4.0 Ah | 150 |
| 5.2 Ah | 180 |
| 6.0 Ah | 225 |
| 8.0 Ah | 300 |

Test setup:

1) -