



# Einhell

# EXPERT

## POWER X-CHANGE

**Cordless All Purpose Saw**

**TE-AP 18/13 Li - Solo**

**Item No.: 4326315**

Ident No.: 21013

Bar Code: 4006825678284

The Einhell TE-AP 18/13 Li-Solo cordless all purpose saw is a particularly lightweight, handy saw for flexible use around the home and garden. It is part of the powerful Power X-Change family. Thanks to its low weight and ergonomic design with soft grip, the reciprocating saw can also be operated with one hand. The reciprocating saw works with a 13 mm stroke height and a cutting capacity of up to 50 mm in wood. The power can be precisely adjusted using the rpm speed electronics. The saw blade can be exchanged without tools and the saw shoe can be adjusted using the hexagon socket key which is stored and supplied in the housing. The cordless universal saw is delivered without a battery or charging device.

## Features & Benefits

- Member of the Power X-Change family, 1 x 18 V battery required
- Multipurpose: Construction site – Workshop – Garden
- Tool-free blade change for quick use
- Extra compact design for easy handling
- Lightweight, handy design suitable even for one-handed work
- Ergonomic handling with optimum grip thanks to the softgrip
- Including 1x quality saw blade each for wood and metal
- Delivered without battery or charging device (available separately)



## Technical Data

- Number of strokes	3000 min <sup>-1</sup>
- Stroke height	13 mm
- Cutting depth in wood	50 mm
- Cutting depth in plastic	10 mm
- Cutting depth in steel	4 mm
- Toolless saw blade change	yes

## Logistic Data

- Product weight	1.13 kg
- Gross weight single packaging	1.73 kg
- Dimensions single packaging	414 x 81 x 159 mm
- Pieces per export carton	6 Pieces
- Gross weight export carton	10.66 kg
- Dimensions export carton	490 x 430 x 185 mm
- Container quantity (20"/40"/40"HC)	4308   8760   10200



## Available as special accessories



Sä-Sägebl.Set 3tg Ho/Met Akku  
Universalsägen-Zubehör  
Item No.: 49576105  
Bar Code: 4009315761053  
Einhell Accessory



5,2 Ah Power X-Change Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



PXC 18V 3,0Ah  
Battery  
Item No.: 4511341  
Bar Code: 4006825590593  
Einhell Accessory



3,0 Ah Power X-Change Plus  
Battery  
Item No.: 4511501  
Bar Code: 4006825644197  
Einhell Accessory



2,0 Ah Power X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



4,0 Ah Power X-Change  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change  
Plus  
Battery  
Item No.: 4511502  
Bar Code: 4006825644210



2x18V 4,0Ah PXC-Twinpack CB  
B1  
Battery  
Item No.: 4511489  
Bar Code: 4006825638578



2x2 Power X-Quattrocharger 4A  
Charger  
Item No.: 4512102  
Bar Code: 4006825649536  
Einhell Accessory



Power X-Fastcharger 4A  
Charger  
Item No.: 4512103  
Bar Code: 4006825650228  
Einhell Accessory



Power X-Twincharger 3A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



Power X-Car Charger 3A  
Charger  
Item No.: 4512113  
Bar Code: 4006825655377  
Einhell Accessory



18V 2,5Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512097  
Bar Code: 4006825646962  
Einhell Accessory



18V 4,0Ah PXC Starter Kit A1  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



18V 2,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512040  
Bar Code: 4006825613681  
Einhell Accessory



E-Case L with wheels  
System Carrying Case  
Item No.: 4540014  
Bar Code: 4006825660562  
Einhell Accessory



E-Case S-F  
System Carrying Case  
Item No.: 4540011  
Bar Code: 4006825653991  
Einhell Accessory



E-Case M  
System Carrying Case  
Item No.: 4540021  
Bar Code: 4006825667721  
Einhell Accessory

## Battery-Running-Times

One Battery for All

  
sawing<sup>1</sup>  
(pieces)

One Battery for All	sawing <sup>1</sup> (pieces)
1.5 Ah	185
2.0 Ah	242
2.5 Ah	313
3.0 Ah	369
4.0 Ah	484
5.2 Ah	629
6.0 Ah	726
8.0 Ah	976

Test setup:

1) softwood - round soft wood Ø 35 mm