



Einhell

EXPERT



Cordless Impact Driver

TE-CI 18/160 Li-Solo

Item No.: 4510044

Ident No.: 21014

Bar Code: 4006825682427

The Einhell TE-CI 18/160 Li-Solo cordless impact wrench can effortlessly turn in large or long screws with up to 160 Nm of torque. The impact wrench protects the wrists of the users due to the special impact mechanism. As a member of the Einhell Power X-Change family, the cordless impact wrench can be combined with all batteries and chargers in the system family. It is equipped with a 1/4-inch hex socket. The speed control can be finely dosed for material-appropriate work. An integrated LED light ensures optimum visibility, and the belt clip allows the device to be stored quickly and easily on the belt. Supplied without battery and charger.

Features & Benefits

- Member of the Power X-Change family, 1x 18 V battery required
- Finely adjustable speed control for sensitive work
- Quick-stop for fast and easy tool changes
- Robust internal hexagon chuck
- Special impact mechanism protects wrist from twisting forces
- Lightweight design with ergonomically shaped soft grip surfaces
- LED light to illuminate the work area
- Includes belt clip for easy interim storage
- Delivery without battery and charger (sold separately)

Technical Data

- | | |
|-------------------------|--------------------------|
| - Idle speed | 2300 min ⁻¹ |
| - Type of bit interlock | Mechanic locking sleeve |
| - tool collet (hex) | Bit holder (6,35mm/1/4") |
| - Max. torque hard | 160 Nm |

Logistic Data

- | | |
|--------------------------------------|--------------------|
| - Product weight (kg) | 1.1 |
| - Gross weight (kg) | 1.35 |
| - Pieces per export carton | 10 Pieces |
| - Gross weight export carton | 14.3 kg |
| - Dimensions Export Carton | 420 x 350 x 218 mm |
| - Container quantity (20"/40"/40"HC) | 8630 18090 |



18 V

**160 Nm
HIGH
POWER**



Available as special accessories



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
A1
Battery
Item No.: 4511489
Bar Code: 4006825638578



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



4Ah PLUS PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512159
Bar Code: 4006825680331
Einhell Accessory



PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



18V 4,0Ah PXC Starter Kit A1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



Handy Bitbox Impact 12tlg.
Akku-Bohrschrauber-Zubehör
Item No.: 49155025
Bar Code: 4009311550255
Einhell Accessory



5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



5,2 Ah PXC Starter-Kit
PXC-Starter-Kit
Item No.: 4512147
Bar Code: 4006825675153
Einhell Accessory



PXC 18V 4,0Ah
Battery
Item No.: 4514079
Bar Code: 4006825674316
Einhell Accessory (Discounter)



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210

Battery-Running-Times

One Battery for All	fastening and releasing ¹ (pieces)
1.5 Ah	140
2.0 Ah	185
2.5 Ah	230
3.0 Ah	280
4.0 Ah	370
5.2 Ah	520
6.0 Ah	560
8.0 Ah	740

Test setup:
1) wheel nuts