



Band Saw BT-SB 200

QUICK START GUIDE

Easy steps to getting started.

1. Ensure all items, including your manual are removed from the packaging before discarding.
2. Before using the band saw, make sure it stands securely, is properly assembled and the blade is correctly fitted.
3. To assemble the band saw and adjust the saw blade (26), please refer to Section 7. of the User Guide for detailed instructions.
4. To turn the band saw on, press the green button 'I' of the ON/OFF switch (1). To turn the band saw off, press the red button 'O' of the ON/OFF switch (1).
5. To perform longitudinal cuts, mount the parallel stop (24) to the band saw as described in Section 8.2. and 9.1 of the User Guide.
6. To perform angular cuts, the saw table (15) can be tilted between 0–45°. Refer to Section 8.3 of the User Guide for more details.
7. To perform freehanded cuts (e.g. curved cuts), refer to Section 9.3 of the User Guide for more details.
- 8. IF YOU ARE IN ANY DOUBT PLEASE REFER TO THE DETAILED INSTRUCTIONS WITHIN OUR USER GUIDE.**

