




STAPLE GUN

INSTRUCTION MANUAL


SPECIFICATIONS

Voltage:	18V
Firing Rate:	60/min
Staple Type:	18 Gauge, 5.7mm Narrow Crown
Staple Length:	10-38mm
Magazine Capacity:	100 Staples
Noise Rating:	84dB
Tool Weight:	2.8kg


ozito.com.au




STANDARD EQUIPMENT



Staple Gun



38mm Staples x 500



Belt Clip, Hex Key

5 YEAR
REPLACEMENT WARRANTY

PXSGS-218

WARRANTY

IN ORDER TO MAKE A CLAIM UNDER THIS WARRANTY YOU MUST RETURN THE PRODUCT TO YOUR NEAREST BUNNINGS WAREHOUSE WITH YOUR BUNNINGS REGISTER RECEIPT. PRIOR TO RETURNING YOUR PRODUCT FOR WARRANTY PLEASE TELEPHONE OUR CUSTOMER SERVICE HELPLINE:

Australia 1800 069 486

New Zealand 0508 069 486

TO ENSURE A SPEEDY RESPONSE PLEASE HAVE THE MODEL NUMBER AND DATE OF PURCHASE AVAILABLE. A CUSTOMER SERVICE REPRESENTATIVE WILL TAKE YOUR CALL AND ANSWER ANY QUESTIONS YOU MAY HAVE RELATING TO THE WARRANTY POLICY OR PROCEDURE.

WARNING

The following actions will result in the warranty being void.

- If the tool has been operated on a supply voltage other than that specified on the tool.
- If the tool shows signs of damage or defects caused by or resulting from abuse, accidents or alterations.
- Failure to perform maintenance as set out within the instruction manual.
- If the tool is disassembled or tampered with in any way.
- Professional, industrial or high frequency use.

The benefits provided under this warranty are in addition to other rights and remedies which are available to you at law.

Our goods come with guarantees that cannot be excluded at law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Generally you will be responsible for all costs associated with a claim under this warranty, however, where you have suffered any additional direct loss as a result of a defective product you may be able to claim such expenses by contacting our customer service helpline above.


5 YEAR REPLACEMENT WARRANTY

Your Product is guaranteed for a period of 60 months from the original date of purchase and is intended for DIY (Do It Yourself) use only. If a product is defective it will be replaced in accordance with the terms of this warranty. **Lithium Ion batteries and chargers are covered by a 36 month warranty** and are excluded from the warranty extension. Warranty excludes consumable parts.

KNOW YOUR PRODUCT

STAPLE GUN

- | | |
|--------------------------------|-----------------------------|
| 1. Fire Trigger | 8. Magazine Slider |
| 2. Sure Grip Handle | 9. Staple Magazine |
| 3. Fire Type Adjustment Switch | 10. LED |
| 4. Battery Seating | 11. Replacement Striker Cap |
| 5. Belt Clip | 12. Staple Level Indicator |
| 6. Magazine Slider Release | 13. Safety Striker |
| 7. Depth Setting Dial | 14. Cover Plate |



BATTERY & CHARGER

This tool is compatible with all batteries & chargers from the Ozito PXC range.

ONLINE MANUAL

Scan this QR Code with your mobile device to take you to the online manual.



5 YEAR
REPLACEMENT WARRANTY


SETUP & PREPARATION

1. SELECTING STAPLES

Fastener Selection

Accessories to suit this staple gun can be purchased from Bunnings Warehouse.

This tool accepts staples with the following measurements below:



WARNING! THIS TOOL MUST NEVER BE USED ON ANY HARD MATERIALS SUCH AS STONE, METAL, ETC.

2. LOADING THE MAGAZINE



WARNING! ENSURE THE TOOL IS SWITCHED OFF AND THE BATTERY IS REMOVED BEFORE PERFORMING ANY OF THE FOLLOWING TASKS.




WARNING! ENSURE THE TOOL IS NOT POINTED AT YOURSELF OR AT ANYONE ELSE WHEN LOADING THE MAGAZINE.

Loading Staples


This staple gun only accepts 10-38mm Narrow Crown staples. Other types of staples, including paper staples, will jam the unit. For best results, load a full row of staples before use.

1. Press the magazine slider release down and pull the magazine slider out of the tool.




2. Insert a row of staples into the front of the magazine.

Note: Ensure staples are positioned correctly in the magazine and not misaligned or inserted upside down.




3. Push the magazine slider back into the unit until it clips into place.



3. FITTING THE BATTERY


Installing the Battery Pack

Slide the battery into the tool base until it clicks into place.



Removing the Battery Pack

Hold down the battery release button as you slide the battery out.



WARNING! REMOVE THE BATTERY FROM THE TOOL BEFORE REMOVING OR LOADING FASTENERS INTO THE MAGAZINE. FAILURE TO DO SO COULD RESULT IN SERIOUS PERSONAL INJURY.

OPERATION

4. DRIVING STAPLES

The staple gun is designed for example tacking down fabrics such as attaching canvas to paint frames, replacing upholstery fabric or stapling down carpet.

WARNING! ALWAYS USE BOTH HANDS WHEN USING THE TOOL.

WARNING! ALWAYS WEAR EYE & EAR PROTECTION.

This tool has two firing methods: **Single Fire** and **Bump Fire**. This allows for driving staples in different ways for precise accuracy or speed.


Note: Test fire on scrap piece of wood to get the exact placement of the staple relative to the gun before use.

Note: The LED glows when you press the trigger.


Single Fire

This method will fire one fastener only when the tool is pushed against the work surface and each time the trigger is pressed, this is an accurate and more precise method of firing fasteners.


1. Push the Fire Type Adjustment Switch upwards for a single fire.



2. Hold the Sure Grip handle firmly and push the safety striker on the material until it is compressed completely



3. To fire, press the trigger once and let it go to fire one fastener.




4. To fire again; first remove the safety striker from the material.

5. Repeat the procedure from step 2 for the next fastener.


Bump Fire

This method will fire a fastener with the trigger pressed as you bump the tool along the workpiece making contact at the points where you want to insert the fastener. This method is less accurate but is a much faster firing method.

1. Push the Fire Type Adjustment Switch downwards for a continuous fire.



2. Press the trigger and then bump the safety striker on the material to fire a fastener; each time the safety striker hits the material with the trigger pressed a single fastener will fire.



WARNING! DO NOT CLAMP OR HOLD THE TRIGGER WITH ANYTHING OTHER THAN YOUR HAND.

WARNING! DO NOT OVER REACH! KEEP PROPER FOOTING AND BALANCE AT ALL TIMES.


Note: To prevent the cordless staple gun from overheating, it is suggested to allow the tool to rest for 20mins after approx 500 shots in continuous fire mode and do not exceed a stapler firing rate of 60 shots per minute.

Staple Firing Force Adjustment

The driving depth of the fastener may be adjusted. The depth of drive is made by rotating the Depth adjustment dial.

- If the fastening is driven into the workpiece at an excessive depth (the staple head is driven below the work surface), turn the dial in the direction (-).

- If the fastener is protruding (the staple head is not flush with the surface), turn the dial in the direction (+), the staples will be fired deeper.




Note: Always test the setting on a piece of scrap material after making any adjustments.

MAINTENANCE

**WARNING!** BEFORE CLEANING OR CARRY OUT ANY MAINTENANCE PROCEDURE, ENSURE THAT THE BATTERY HAS BEEN REMOVED.

Jammed Staple

1. Remove the battery from the tool.
2. Press the magazine slider release down and pull the magazine slider out of the tool.
3. Undo the four screws from the cover plate with the supplied hex key.
4. Remove the cover plate.
5. With a pair of pliers (not included), remove the jammed staples.
6. Refit the cover plate. Take care to fit in the right direction and order.
7. Screw the cover plate securely back in place.



Cleaning

- Keep the ventilation slots of the tool clean at all times to ensure efficient operation.
- After each use, blow air through the tool housing to ensure it is free from all dust, dirt, etc. Build up of dust or dirt particles may cause the tool to overheat and shorten the life of the tool.
- If the housing of the tool requires cleaning, do not use solvents. Use of a cloth only is recommended.
- Never allow any liquid to get inside the tool, never immerse any part of the tool into liquid.

Storage & Transport

- Store the equipment and its accessories in a dark and dry place at above freezing temperature, out of children’s reach. The ideal storage temperature is between 5°C and 30°C.
- Switch the machine off and remove the battery before transporting or storing the staple gun.
- Transport and store in original packaging.

Note: Ozito Industries will not be responsible for any damage or injuries caused by repair of the staple gun by an unauthorised person or by mishandling.

DESCRIPTION OF SYMBOLS

V	Volts	mm	Millimeters
	Direct Current		Warning
/min	Revolutions or reciprocations per minute		Regulatory Compliance Mark (RCM)
	Wear eye & ear protection	Ah	Ampere Hour
	Read Instruction Manual		

CARING FOR THE ENVIRONMENT



Power tools that are no longer usable should not be disposed of with household waste but in an environmentally friendly way. Please recycle where facilities exist. Check with your local council authority for recycling advice.



Recycling packaging reduces the need for landfill and raw materials. Reuse of recycled material decreases pollution in the environment. Please recycle packaging where facilities exist. Check with your local council authority for recycling advice.

SPARE PARTS

Spare parts can be ordered from the Special Orders Desk at your local Bunnings Warehouse.

For further information, or any parts not listed here, visit www.ozito.com.au or contact Ozito Customer Service:

Australia 1800 069 486

New Zealand 0508 069 486

E-mail: hello@ozito.com.au

ELECTRICAL SAFETY



WARNING! When using mains-powered tools, basic safety precautions, including the following, should always be followed to reduce risk of fire, electric shock, personal injury and material damage.

Read the whole manual carefully and make sure you know how to switch the tool off in an emergency, before operating the tool.

Save these instructions and other documents supplied with this tool for future reference.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- This appliance is compatible and only to be used with all batteries & chargers from the Ozito PXC range. Refer to the PXC battery and charger manuals for information regarding charging, use and storage.

GENERAL POWER TOOL SAFETY WARNINGS



WARNING! Read all safety warnings and all instructions. Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.

Save all warnings and instructions for future reference. The term “power tool” in the warnings refers to your mains-operated (corded) power tool or battery-operated (cordless) power tool.

1. Work area safety

- Keep work area clean and well lit.** Cluttered or dark areas invite accidents.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.** Power tools create sparks which may ignite the dust or fumes.
- Keep children and bystanders away while operating a power tool.** Distractions can cause you to lose control.

2. Electrical safety

- Power tool plugs must match the outlet.** Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools. Unmodified plugs and matching outlets will reduce risk of electric shock.
- Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators.** There is an increased risk of electric shock if your body is earthed or grounded.
- Do not expose power tools to rain or wet conditions.** Water entering a power tool will increase the risk of electric shock.
- Do not abuse the cord.** Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of electric shock.
- When operating a power tool outdoors, use an extension cord suitable for outdoor use.** Use of a cord suitable for outdoor use reduces the risk of electric shock.
- If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply.** Use of an RCD reduces the risk of electric shock.

3. Personal safety

- Stay alert, watch what you are doing and use common sense when operating a power tool.** Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating power tools may result in serious personal injury.
- Use personal protective equipment.** Always wear eye protection. Protective equipment such as dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.
- Prevent unintentional starting.** Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool. Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.
- Remove any adjusting key or wrench before turning the power tool on.** A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
- Do not overreach.** Keep proper footing and balance at all times. This enables better control of the power tool in unexpected situations.
- Dress properly.** Do not wear loose clothing or jewellery. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewellery or long hair can be caught in moving parts.
- If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used.** Use of dust collection can reduce dust-related hazards.
- Do not let familiarity gained from frequent use of tools allow you to become complacent and ignore tool safety principles.** A careless action can cause severe injury within a fraction of a second.

WARNING! Always remove the battery from the tool:

- when the batteries are to be charged,
 - when the tool is left unattended,
 - when the tool is being checked, cleaned, or having maintenance work done,
 - when the tool is to be stored,
 - or if the tool vibrates abnormally.
- Do not combine different types of batteries or new and used batteries.
- Do not use modified or damaged batteries.

4. Power tool use and care

- Do not force the power tool.** Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.
- Do not use the power tool if the switch does not turn it on and off.** Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
- Disconnect the plug from the power source and/or the battery pack from the power tool before making any adjustments, changing accessories, or storing power tools.** Such preventive safety measures reduce the risk of starting the power tool accidentally.
- Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool.** Power tools are dangerous in the hands of untrained users.
- Maintain power tools.** Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.
- Keep cutting tools sharp and clean.** Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
- Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed.** Use of the power tool for operations different from those intended could result in a hazardous situation.
- Keep handles and grasping surfaces dry, clean and free from oil and grease.** Slippery handles and grasping surfaces do not allow for safe handling and control of the tool in unexpected situations.

5. Battery tool use and care

- Recharge only with the charger specified by the manufacturer.** A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.
- Use power tools only with specifically designated battery packs.** Use of any other battery packs may create a risk of injury and fire.
- When battery pack is not in use, keep it away from other metal objects, like paper clips, coins, keys, nails, screws or other small metal objects, that can make a connection from one terminal to another.** Shorting the battery terminals together may cause burns or a fire.
- Under abusive conditions, liquid may be ejected from the battery; avoid contact. If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help.** Liquid ejected from the battery may cause irritation or burns.
- Do not use a battery pack or tool that is damaged or modified.** Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire, explosion or risk of injury.
- Do not expose a battery pack or tool to fire or excessive temperature.** Exposure to fire or temperature above 130 °C may cause explosion.
- Follow all charging instructions and do not charge the battery pack or tool outside the temperature range specified in the instructions.** Charging improperly or at temperatures outside the specified range may damage the battery and increase the risk of fire.

6. Service

- Have your power tool serviced by a qualified repair person using only identical replacement parts.** This will ensure that the safety of the power tool is maintained.
- Never service damaged battery packs.** Service of battery packs should only be performed by the manufacturer or authorized service providers.

STAPLE GUN SAFETY WARNINGS



WARNING! This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

- **Always assume that the tool contains fasteners.** Careless handling of the stapler can result in unexpected firing of fasteners and personal injury.
- **Do not point the tool towards yourself or anyone nearby.** Unexpected triggering will discharge the fastener causing an injury.
- **Do not actuate the tool unless the tool is placed firmly against the workpiece.** If the tool is not in contact with the workpiece, the fastener may be deflected away from your target.
- **Disconnect the tool from the battery when the fastener jams in the tool.** While removing a jammed fastener, the tackler may be accidentally activated if it is plugged in.
- **Do not use this stapler for fastening electrical cables.** It is not designed for electric cable installation and may damage the insulation of electric cables thereby causing electric shock or fire hazards.

- **Always use both hands to operate the tool.** Your secondary hand should be used to press the back of the tool firmly down onto the surface to be fastened.
- **Do Not** point the LED into the eyes of humans or animals.
- **Avoid using power tools for long periods of time without breaks.** Vibration from tools can be transmitted into your hands and arms.
- **Where possible, use clamps or a vice to hold the workpiece.** It is safer than using your hand.
- **Use caution while removing a jammed fastener.** The mechanism may be under compression and the fastener may be forcefully discharged while attempting to free a jammed condition.



WARNING! When servicing, use only identical replacement parts. Use of any other parts may create a hazard or cause product damage. To ensure safety and reliability, all repairs should be performed by a qualified service