

Guarantee

We grant a **three-year guarantee** from the date of purchase.

This product was manufactured using the latest production techniques and has undergone thorough quality control inspection. We guarantee that the product is in perfect condition.

We will remedy all defects in workmanship or materials within the guarantee period. In order for the guarantee to be granted, all warranty claims must be accompanied by proof of purchase from Tchibo or from an authorised Tchibo distribution partner.

If, contrary to our expectations, a defect is found, please contact our customer care service at the following e-mail address:

service@tchibo.de

Our customer consultants will be pleased to advise you on further procedure.

Damage due to improper use, as well as worn parts and consumables, are not covered by the guarantee.


Please have the product number at hand in case of any queries.

This guarantee does not restrict statutory warranty rights.

Product number: EN 301 226



Cordless Screwdriver



Original instructions for use and guarantee

Tchibo GmbH D-22290 Hamburg • 72241AB1X1V

Dear Customer

With your useful, new cordless screwdriver you can complete odd jobs around the home in the blink of an eye. The practical LED light makes it easy to work even in dark corners, while the magnetic screw holder keeps your hands free. You can use the capacity display to check the battery's charge - so the cordless screwdriver is always ready for operation.

We hope you will enjoy using your new cordless screwdriver.

Your Tchibo Team

Contents


2	About these instructions	11	Use
4	General safety warnings for power tools (according to the German Industrial Standard DIN EN 60745-1)	12	Care / maintenance / storage
6	Information on safe battery usage	13	Disposal
8	Additional information for power tools	14	Technical specifications
9	At a glance (package contents)	15	Declaration of Conformity
10	First-time use	16	Guarantee


About these instructions

This product is equipped with safety features. Nevertheless, read the safety warnings carefully and only use the product as described in these instructions to avoid accidental injury or damage.

Keep these instructions for future reference. If you pass the product on to someone else, be sure to give them these instructions.

Symbols used in these instructions:


 This symbol warns you of the danger of injury.

 This symbol warns you of the danger of injury due to electricity.

The term **DANGER** warns of potential severe injury and danger to life.

The term **WARNING** warns of injury and severe material damage.

The term **CAUTION** warns of minor injury or damage.

 This indicates supplementary information.

Declaration of Conformity

ISC GmbH · Eschenstraße 6 · D-94405 Landau/Isar



Konformitätserklärung

- ☐ erklärt folgende Konformität gemäß EU-Richtlinie und Normen für Artikel
- ☐ explains the following conformity according to EU directives and norms for the following product
- ☐ déclare la conformité suivante selon la directive CE et les normes concernant l'article
- ☐ dichiara la seguente conformità secondo la direttiva UE e le norme per l'articolo
- ☐ verklaart de volgende overeenstemming conform EU richtlijn en normen voor het product
- ☐ declara la siguiente conformidad a tenor de la directiva y normas de la UE para el artículo
- ☐ declara a seguinte conformidade, de acordo com a directiva CE e normas para o artigo
- ☐ attesterer følgende overensstemmelse i medfør af EU-direktiv samt standarder for artikel
- ☐ förklarar följande överensstämmelse enl. EU-direktiv och standarder för artikeln
- ☐ vakuuttaa, että tuote täyttää EU-direktiivin ja standardien vaatimukset
- ☐ tõendab toote vastavust EL direktiivile ja standarditele
- ☐ vydává následující prohlášení o shodě podle směrnic EU a norem pro výrobek
- ☐ potvrđuje sledeću skladnost s smernico EU in standardi za izdelek
- ☐ vydáva nasledujúce prehlásenie o zhode podľa smernice EÚ a noriem pre výrobok
- ☐ a cikkhez az EU-irányvonal és Normák szerint a következő konformitást jelenté ki
- ☐ deklaruje zgodność wymienionego poniżej artykułu z następującymi normami na podstawie dyrektywy WE.
- ☐ декларира съответното съответствие съгласно Директива на ЕС и норми за артикул
- ☐ paskaidro šādu atbilstību ES direktīvai un standartiem
- ☐ apibūdina šj atitiktīgu EU reikalavimams ir prekės normoms
- ☐ declară următoarea conformitate conform directivei UE și normelor pentru articolul
- ☐ δηλώνει την ακόλουθη συμμόρφωση σύμφωνα με την Οδηγία ΕΚ και τα πρότυπα για το προϊόν
- ☐ potvrđuje sljedeću usklađenost prema smjernicama EU i normama za artikl
- ☐ potvrđuje sljedeću usklađenost prema smjernicama EU i normama za artikl
- ☐ potvrđuje sledeću usklađenost prema smernicama EZ i normama za artikali
- ☐ следующим удостоверяется, что следующие продукты соответствуют директивам и нормам ЕС
- ☐ проголошує про зазначену нижче відповідність виробу директивам та стандартам ЄС на виріб
- ☐ ja izjavuva slednata soobraznost согласно EY-direktivata и нормите за артикли
- ☐ Ürünü ile ilgili AB direktifleri ve normları gereğince aşağıda açıklanan uygunluğu belirtir
- ☐ erklærer følgende samsvar i henhold til EU-direktivet og standarder for artikkel
- ☐ Lysir uppfylling EU-reglina og annarra staðla vöru

Akkuschrauber T-AS 3,6-3 / Ladegerät für T-AS 3,6-3 (Tchibo)

- 87/404/EC_2009/105/EC
- 2005/32/EC_2009/125/EC
- 2006/95/EC
- 2006/28/EC
- 2004/108/EC
- 2004/22/EC
- 1999/5/EC
- 97/23/EC
- 90/396/EC_2009/142/EC
- 89/686/EC_96/58/EC
- 2011/65/EC
- 2006/42/EC
- Annex IV
Notified Body:
Notified Body No.:
Reg. No.:
- 2000/14/EC_2005/88/EC
- Annex V
- Annex VI
Noise: measured L_{WA} = dB (A); guaranteed L_{WA} = dB (A)
 P = KW; L/D = cm
Notified Body:
- 2004/26/EC
Emission No.:

Standard references: EN 60745-1; EN 60745-2-2; EN 55014-1;
EN 55014-2; EN 61000-3-2; EN 61000-3-3; EN 60335-1; EN 60335-2-29

Landau/Isar, den 10.07.2013

Weichselgartner/General Manager

Yang/Product-Management

First CE: 06
Art.-No.: 45.107.19 I.-No.: 11013
Subject to change without notice

Archive-File/Record: NAPR008579
Documents registrar: Georg Riedel
Wiesenweg 22, D-94405 Landau/Isar

Technical specifications

Model:	301 226
Mains adapter:	Input: 230 V ~ 50 Hz Output: 6 V --- 300 mA $\oplus \ominus$ Protection class : II \square Power consumption: 6.5 W
Rechargeable battery :	Type : 1x lithium-ion, 1.3Ah Charging voltage: 6 V --- Charging current: 300 mA Charging time: max. 5 hours
Motor:	Voltage: 3.6 V --- Idling speed: 200 rpm Clockwise/anticlockwise: yes
Sound pressure level	L _{pA} = 59 dB(A) Uncertainty K _{pA} = 3 dB
Sound power level	L _{WA} = 70 dB(A) Uncertainty K _{WA} = 3 dB
Vibration emission value	a _H ≤ 0.291 m/s ² Uncertainty K = 1.5 m/s ²
Weight:	approx. 0.4 kg
Ambient temperature:	Operation: +10 to +40 °C Storage: +5 to +30 °C



ISC GmbH
Eschenstraße 6, 94405 Landau/Isar, Germany



WARNING - Read the instructions for use to reduce the risk of injury.



Wear ear protectors. Exposure to noise may cause hearing loss.



Wear protective glasses.

Sparks produced as you work or splinters, shavings and dust produced by the screwdriver may cause loss of sight.

Intended use

The cordless screwdriver is intended for screwing in and loosening screws.

The machine may only be used for its intended purpose. Any other use is considered improper. The user/operator is liable for any damage or injuries caused in this way, not the manufacturer. The product is designed for home use and is not suitable for commercial purposes.

DANGER to children and people with restricted capabilities of operating appliances

- This device is not intended for use by children or those who lack the physical, sensory or mental capabilities, or the experience and knowledge to be able to use it safely. Children should be supervised to ensure that they do not play with the device.
- The device and packaging material are not toys! Children must not play with plastic bags, films and small parts! There is a risk of choking or suffocation!

DANGER due to electricity

- The device must not be used in rooms subject to explosion hazards.
- Protect the product from moisture. Water penetrating an electrical device increases the risk of electric shock.
- Do not touch the mains adapter with moist hands. Do not use it outdoors or in rooms with high humidity.
- Check before use that all moving parts are working correctly and do not jam and that no parts are broken or damaged in such a way as to impair the function of the device. Do not operate the device if the device itself or the mains adapter show visible signs of damage or if the device has been dropped.

- Unplug the mains adapter from the wall socket in the event of a technical fault or during thunderstorms. Always pull on the mains adapter, never on the mains cord.
- Do not make any modifications to the product or try to replace the mains cord yourself. Have repairs to the device or mains adapter carried out by a specialist workshop only or contact the customer care service.
- The device contains lithium-ion rechargeable batteries. These cannot and must not be replaced. If the rechargeable batteries are damaged, contact the customer care service. Never attempt to open the casing. The device must not be used if there is damage to the casing.

WARNING - risk of injury

- Do not let people use the device who are not familiar with it or who have not read the instructions for use.
- Avoid starting the device accidentally.
- Do not use flawed or damaged attachments.
- For your own safety, only use accessories or auxiliary equipment specified in the instructions for use or those recommended by the tool manufacturer. The use of accessories other than those recommended in the instructions for use may lead to personal injury.
- Never use an electrical tool with a defective switch. A power tool that can no longer be switched on or off is dangerous and must be repaired.

CAUTION - material damage

- There is an LED light installed in the device. This cannot and must not be replaced.

**General safety warnings for power tools
(according to the German Industrial Standard DIN EN 60745-1)**



WARNING! Read all safety warnings and instructions. Failure to follow all safety warnings and instructions listed below may result in electric shock, fire and/or serious injury.

Keep all safety warnings and instructions so that you can refer to them later on. The term "power tool" in the safety warnings refers to electrical mains powered tools (with mains cord) or battery operated tools (without mains cord).

1) Work area

- a) **Keep the work area clean and well lit.** Cluttered and dark areas can lead to accidents.
- b) **Do not operate power tools in flammable areas, such as in the presence of flammable liquids, gases or dust.** Power tools create sparks which may ignite the dust or fumes.
- c) **Keep children and bystanders away while operating a power tool.** Distraction can cause you to lose control of the power tool.

2) Electrical safety

- a) **Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed power tools.** Unmodified plugs and matching outlets will reduce the risk of electric shock.
- b) **Avoid any contact with earthed or grounded surfaces such as pipes, radiators, stoves and refrigerators.** There is an increased risk of electric shock if your appliance or system is earthed or grounded.
- c) **Do not expose power tools to rain or wet conditions.** Water getting into a power tool will increase the risk of electric shock.
- d) **Do not misuse the cord. Never carry the power tool by the cord or pull on the cord to remove the plug from the outlet. Keep the cord away from heat, oil, sharp edges or moving parts.** Damaged or tangled cords increase the risk of electric shock.
- e) **When operating a power tool outdoors, use an extension cord suitable for outdoor use.** Using a cord suitable for outdoor use reduces the risk of electric shock.
- f) **If use of a power tool in a humid location is unavoidable, use a residual current differential device (RCD).** The use of an RCD reduces the risk of electric shock.

3) Personal safety

- a) **Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication.** A moment of inattention while operating power tools may result in serious personal injury.
 - b) **Use safety equipment. Always wear eye protection.** Safety equipment such as dust masks, non-skid safety shoes, hard hats or hearing protection used for appropriate conditions will reduce the risk of personal injuries.
 - c) **Avoid starting the drill unintentionally. Make sure that the switch is in the off position before plugging the tool into the mains and/or inserting the rechargeable batteries, picking up the tool or carrying it.** Carrying power tools with your finger on the switch or plugging in power tools while they are switched on may lead to accidents.
 - d) **Remove any adjustment keys or wrenches before turning the power tool on.** A wrench or a key left attached to a rotating part of the power tool can result in personal injury.
 - e) **Do not overreach. Keep a proper position at all times. Keep proper footing and balance at all times.** This enables better control of the power tool in unexpected situations.
 - f) **Dress properly. Do not wear loose clothing or jewellery. Keep your hair, clothing and gloves away from moving parts.** Loose clothing, jewellery or long hair can get caught in moving parts.
 - g) **If vacuum devices are provided for dust removal, make sure these are properly connected and used.** Using dust collectors can reduce dust-related risks.
- 4) Use and maintenance of a power tool**
- a) **Do not overload the power tool. Use the appropriate power tool for your needs.** You will get the job done better and safer if using tools for their intended purpose.
 - b) **Do not use the power tool if the switch does not turn it on and off.** Any power tool that cannot be controlled with the switch is dangerous and must be repaired.

Disposal

The products, its packaging and the built-in rechargeable battery have been manufactured from valuable materials that can be recycled. Recycling reduces the amount of waste and helps to preserve the environment.

Dispose of the **packaging** at a recycling point, which sorts materials by type. Make use of the local facilities provided for collecting paper, cardboard and lightweight packaging.



Devices marked with this symbol must not be disposed of along with household waste!

You are legally bound to dispose of old devices separately from household waste. Information about the collection point where old devices can be disposed of free of charge is available from your local authorities.



Regular batteries and rechargeable batteries must not be disposed of along with normal household refuse!

You are legally bound to dispose of flat batteries and rechargeable batteries at a local authority collection point or to return them to a battery retailer.

**Pb
Cd
Hg**

Regular batteries and rechargeable batteries marked with these letters contain the following, and other, harmful substances:

Pb = lead, Cd = cadmium, Hg = mercury.

Care / maintenance / storage



DANGER - risk of fatal electric shock

- Remove the mains adapter from the wall socket before cleaning the device.
- The device must not be exposed to moisture. It must also be protected against drops and splashes of water.



WARNING - risk of injury

- Before cleaning, slide the rotation direction switch into the central position to lock the On/Off switch.

Cleaning

CAUTION - material damage

- Do not use any cleaning or solvent-based products as these could corrode the plastic parts.

Clean the device as soon as possible after each use. In particular, keep the air slots and switches free from dust and dirt.

- ▷ Wipe off dust and similar dirt particles with a dry cloth or use compressed air at a low pressure.
- ▷ Clean the device regularly with a damp cloth and some soft soap. Ensure that no water gets inside the device!

Maintenance

The device does not require any maintenance.

Storage

- Store the device and its accessories in a dark, dry and frost-free place out of the reach of children.
- The optimum storage temperature is between +5 and +30°C.
- Store the cordless screwdriver in the storage case supplied.
- ▷ Charge the battery before storing the device.
- ▷ Also note the information on storing batteries in "Information on safe battery usage".

- c) **Disconnect the plug from the power source and/or remove the rechargeable battery before making any adjustments, changing accessories, or storing power tools.** *Such preventive safety measures reduce the risk of starting power tools accidentally.*
- d) **Store power tools out of the reach of children when not in use and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool.** *Power tools are dangerous in the hands of untrained users.*
- e) **Maintain power tools. Make sure that none of the moving parts are misaligned or damaged, that no parts are broken and that there are no other conditions that could affect a power tool's operation. If damaged, have the power tool repaired before use.** *Many accidents are due to badly maintained power tools.*
- f) **Keep cutting tools sharp and clean.** *Properly maintained cutting tools with sharp cutting edges are less likely to jam and easier to control.*
- g) **Use the power tool, accessories and attachments, etc. in accordance with these instructions while taking into account the work conditions and the work to be done.** *Using power tools in ways for which they were not intended could result in hazardous situations.*

5) Use and maintenance of the rechargeable power tool

- a) **Only charge batteries in battery chargers that were recommended by the manufacturer.** *If the battery charger is designed for a certain type of battery, there is a risk of fire if it is used with different batteries.*
- b) **Only use the batteries provided in the power tools.** *The use of other rechargeable batteries can result in injuries or fire.*
- c) **Store the unused battery away from paperclips, coins, keys, nails, screws or any other small metallic objects that could cause bridging between the contacts.** *A short circuit between the battery contacts can cause burns or fire.*

- d) **Incorrect use may result in fluid escaping from the battery. Avoid contact with this fluid. In case of accidental contact, rinse with water. If the fluid gets into your eyes, seek medical assistance.** *Leaking battery fluid can result in skin irritation or burns.*

6) Service

- a) **Have your power tool repaired by qualified experts using only identical replacement parts.** *This will ensure that the safety of the power tool is maintained.*

7) Information on using the screwdriver

Hold the device by the insulated handle when carrying out work in areas where the screw or the insertion tool might encounter concealed power cables. *Contact with a live cable can also transfer voltage to metal parts and cause an electric shock.*

Information on safe battery usage



Despite extensive safety precautions, caution is always required when handling batteries. To ensure safe operation, the following points must always be observed.

Safe operation is only guaranteed with undamaged cells! Incorrect handling can result in cell damage.

Caution! Analyses confirm that improper use and incorrect care are the main causes of damage in high-performance batteries.

Battery information

- The battery pack in the battery-operated tool is not charged upon delivery. The battery must be charged before first-time use.
- For optimal battery performance avoid complete discharge cycles! Charge the battery regularly.
- Store the battery in a cool place, ideally at 15°C and at least 40% charged.
- Lithium-ion batteries undergo a natural ageing process. The batteries must be replaced at the latest when the battery capacity amounts to only 80% of when they were new. Weakened cells in an old battery pack no longer measure up to the high performance requirements and therefore pose a safety risk.
- Do not throw used batteries into an open fire. Risk of explosion! Do not ignite batteries or expose them to fire.
- **Do not completely discharge the batteries!** Complete discharge damages the battery cells. The most common cause for complete discharge of battery packs is long-term storage or lack of use of partially charged batteries. Stop working as soon as the performance becomes noticeably diminished or the protection circuit is tripped. Only store the battery after charging completely.
- **Protect batteries and device from becoming overloaded!** Overloading quickly leads to overheating and cell damage inside the battery casing without the overheating becoming externally apparent.
- **Avoid damage and impacts!** Replace batteries immediately if they have fallen from a height of more than 1 m or were exposed to a heavy impact, even if the battery pack casing appears undamaged. The battery cells inside could be seriously damaged. Please also observe the information on battery disposal.

- For safety reasons, the integrated safety switch disables the device if it becomes overloaded or overheated. **Caution!** Do not activate the On/Off switch if the safety switch has disabled the device. This can result in damage to the battery.
- Only use the original rechargeable batteries. The use of other rechargeable batteries can result in injuries, explosions or fire.

Notes on the battery charger and charging process

- Please observe the information indicated on the tool identification plate on the battery charger. Only connect the battery charger to the mains voltage indicated on the tool identification plate.
- Protect the battery charger and cable from damage and from sharp edges. Damaged cables must be replaced by an electrician immediately.
- Keep the battery charger, batteries and battery-operated tool away from children.
- Do not use the battery charger if it is damaged.
- Do not use the battery charger provided for charging other battery-operated tools.
- The battery pack becomes warm with heavy use. Allow the battery pack to cool down to room temperature before starting the charging process.
- **Do not overcharge the batteries!** Please observe the maximum charging time. These charging times only apply to discharged batteries. Repeatedly plugging in charged or partially charged batteries overcharges them and damages the cells. Do not leave batteries plugged into the charger for several days at a time.
- **Never charge or use batteries that you suspect were last charged more than 12 months ago.** It is highly likely that the battery is already dangerously damaged (deep discharge).
- Charging at a temperature under 10°C results in chemical damage to the cells and can start a fire.
- Do not use any batteries that have become warm during charging, as the battery cells could be dangerously damaged.

Use

Switching on and off

- ▷ To switch on, press the On/Off switch down fully and hold it pressed down.
- ▷ To switch off, release the On/Off switch.

Setting the rotation direction

CAUTION - material damage


- Only change the rotation direction when it is stationary so that you do not damage the transmission.

- ▷ Slide the rotation direction switch to the left to rotate screws in a **clockwise** direction.
- ▷ Slide the rotation direction switch to the right to rotate screws in an **anticlockwise** direction.
- ▷ Slide the rotation direction switch to the central position to lock the On/Off switch.

Inserting a bit


CAUTION - material damage

- Only use fault-free and suitable bits.
- The device is not designed for drilling, grinding or other similar functions. Do not use any other bits with this device than those provided.
- Before screwing into internal or external walls, check them for electricity, gas or water pipes.



1. Slide the rotation direction switch to the central position to lock the On/Off switch.
 2. Insert the selected bit into the bit holder as far as it will go. The bit holder is magnetic and holds the bit in position.
- ▷ To remove the bit, pull it against the slight resistance out of the bit holder.

Using the bit extension



You can use the bit extension provided for hard to reach work areas. The extension bit holder is also magnetic.

Illuminating the work area

- ▷ To switch on the LED light, slide the light switch forwards.
- ▷ To switch off the LED light, slide the light switch backwards.

Tips for using the screwdriver

- In order to have the required screws ready to use while working, you can place them on the magnetic screw holder on top of the device.
- It is best to use self-centering screws (e.g. Torx, Philips) to ensure safe working.
- Always ensure that the bit and screw used match in shape and size.
- Place the bit on the screw before switching on the device.
- Always hold the device, bit and screw in a straight line.

First-time use

Unpacking

- ▷ Open the packaging and carefully remove the device.
- ▷ Remove all packaging material. Check whether the package contents are complete. Check the device and the accessories for damage from transportation.


Charging the battery

- WARNING** - risk of injury
- Only charge the battery pack with the mains adapter provided.
 - Do not activate the On/Off switch if the integrated safety switch has switched off the device. This can result in damage to the battery.
 - Please also observe the "Information on safe battery usage".

CAUTION

- Do not cover the device and mains adapter during the charging process. Risk of overheating!
- The device must not be used while the battery is charging.

The battery pack in the battery-operated tool is not charged upon delivery. The battery must be charged before first-time use. This takes approx. 5 hours.



1. Insert the plug of the mains adapter into the mains connection socket of the device.
2. Plug the mains adapter into an easily accessible wall socket.

The red battery indicator light will illuminate.

As soon as the battery is fully charged, the battery indicator light goes out.

3. Remove the mains adapter from the wall socket.


The device is now ready for use.

- i** While charging, the handle on the device may become warm. This is normal.

It is necessary to charge the device again as soon as you realise that performance has diminished.

- i** The battery is protected against excessive discharge. An integrated safety switch automatically switches the device off if the battery is discharged. In this case, the bit holder stops rotating. However, in the interest of a long service life for the battery, you should ensure that it is recharged in good time.

Monitoring the charge state of the battery



- ▷ Press the battery capacity display switch. The battery indicator lights light up - according to the state of charge.
- **green-yellow-red**: battery fully charged
- **yellow-red**: battery has sufficient residual charge
- **red**: battery is empty and must be charged

- Do not use any rechargeable batteries that have become distorted or deformed during charging or display other unusual signs (emitting gas, hissing, cracking etc.).
- Do not discharge rechargeable batteries completely (recommended depth of discharge max. 80%). Complete discharge leads to premature ageing of the battery cells.
- Do not leave the rechargeable batteries to charge unattended!

Protection against environmental influences

- Wear appropriate work clothes. Wear protective glasses.
- **Protect your battery-operated tool and the battery charger from moisture and rain.** Moisture and rain can result in dangerous damage to the cells.
- Do not use the battery-operated tool and charger in areas with fumes or combustible liquids.
- Only use the battery-operated tool and charger in dry conditions and at an ambient temperature of 10-40°C.
- Do not store the rechargeable battery in a place where the temperature could reach above 40°C, particularly not in a vehicle parked in the sun.

- **Protect rechargeable batteries from overheating!** Overloading, overcharging or direct sunlight can cause overheating and cell damage. Never charge or work with rechargeable batteries that are overheated - replace them immediately.
- **Storing the rechargeable batteries, charger and battery-operated tool.** Store the charger and your battery-operated tool in a dry room with an ambient temperature of 5-30°C. Protect from humidity and direct sunlight! Only store batteries in a charged condition (min. 40% charged).
- Do not allow the lithium-ion battery to freeze. Batteries that were stored for longer than 60 minutes below 0°C must be disposed of.
- Take care when handling batteries in terms of electrostatic charge: electrostatic discharge causes damage to the protection circuit and the battery cells! Therefore, avoid electrostatic charging and never touch the battery terminals!

For shipping or disposal of rechargeable batteries or the battery-operated tool, ensure that the batteries are packaged separately in a plastic bag to prevent short-circuiting and fire!

Additional information for power tools



Noise and vibration

The noise and vibration values were determined in accordance with EN 60745.

Sound pressure level	$L_{pA} = 59 \text{ dB(A)}$
Uncertainty	$K_{pA} = 3 \text{ dB}$
Sound power level	$L_{WA} = 70 \text{ dB(A)}$
Uncertainty	$K_{WA} = 3 \text{ dB}$



Wear ear protection.

Exposure to noise may cause hearing loss.

Total vibration values (vector sum of three directions) have been determined according to EN 60745.

Screws:

Vibration emission value	$a_h = 0.291 \text{ m/s}^2$
Uncertainty	$K = 1.5 \text{ m/s}^2$

Warning! The stated vibration emission value has been measured according to a standardised test procedure. This can vary depending on the manner in which the power tool is used and, in exceptional cases, may exceed the stated value.

The stated vibration emission value can be used for comparing one power tool with another.

The stated vibration emission value can also be used for initial assessment of damage.

Keep noise generation and vibration to a minimum:

- Do not use flawed or damaged tools.
- Maintain and clean the device regularly.
- Adjust your mode of working to suit the device.
- Do not overload the device.
- Have the device checked as appropriate.
- Switch the device off when it is not being used.
- Wear protective gloves.

Other risks

Even if you operate this power tool correctly there are always further risks. The following hazards may occur in association with the construction and design of this power tool:

- Lung damage if no suitable dust mask is worn.
- Damage to hearing if no suitable ear protection is worn.
- Damage to health resulting from hand and arm vibration if the screwdriver is used for a prolonged period or is not properly maintained and serviced.

At a glance (package contents)

