



280W
MULTI SANDER
RT-XS 28

QUICK START GUIDE

Easy steps to getting started.

1. Ensure all items, including your manual are removed from the packaging before discarding.
2. Slip the dust container (5) onto the vacuum cleaner connector. (a)
3. Ensure that the additional handle is securely engaged in the required position.
4. Fit the appropriate sanding/grinding plate to use the equipment as an orbital sander/grinder.
5. Attach Sand Paper.



**6. IF YOU ARE IN ANY DOUBT PLEASE
REFER TO THE DETAILED INSTRUCTIONS
WITHIN OUR MANUAL.**