

GB

Safety Instructions Chain Sharpener

Please read and save these instructions.

1



“Caution - Read the operating instructions to reduce the risk of injury”



Wear ear-muffs.

The impact of noise can cause damage to hearing.



Wear a breathing mask.

Dust which is injurious to health can be generated when working on wood and other materials. Never use the device to work on any materials containing asbestos!



Wear safety goggles.

Sparks generated during working or splinters, chips and dust emitted by the device can cause loss of sight.

GB**SAFETY INSTRUCTIONS**

Warning! When using electric tools, basic safety precautions should always be followed to reduce the risk of fire, electric shock and personal injury, including the following.

Read all these instructions before attempting to operate this product and save these instructions.

1. **Keep work area clean**
Cluttered areas and benches invite injuries.
2. **Consider work area environment**
Don't expose power tools to rain. Don't use power tools in damp or wet locations. Keep work area well lit. Don't use power tools in presence of flammable liquids or gases.
3. **Guard against electric shock**
Prevent body contact with grounded surfaces (e.g. pipes, radiators, ranges refrigerators).
4. **Keep children away**
Do not let visitors contact tool or extension cord. All visitors should be kept away from work area.
5. **Store idle tools**
When not in use, tools should be stored in dry, high, or locked-up place, out of the reach of children.
6. **Don't force tool**
It will do the job better and safer at the rate for which it was intended.
7. **Use right tool**
Don't force small tools or attachments to do the job of heavy duty tool. Don't use tools for purposes not intended: for example, don't use circular saw for cutting tree limbs or logs.
8. **Dress properly**
Do not wear loose clothing or jewelry. They can be caught in moving parts. Rubber gloves and nonskid footwear are recommended when working outdoors. Wear protective hair covering to contain long hair.
9. **Use safety glasses**
Also use face or dust mask if cutting operation is dusty.
10. **Don't abuse cord**
Never carry tool by cord or yank it to disconnect it from receptacle. Keep cord from heat, oil and sharp edges.
11. **Secure work**
Use clamps or a vise to hold work. It's safer than using your hand and it frees both hands to operate tool.
12. **Don't overreach**
Keep proper footing and balance at all times.
13. **Maintain tools with care**
Keep tools sharp and clean for better and safer performance. Follow instructions for lubricating and changing accessories. Inspect tool cords periodically and, if damaged, have repaired by authorized service facility. Inspect extension cords periodically and replace if damaged. Keep handles dry, clean and free from oil and grease.
14. **Disconnect tools**
When not in use, before servicing, and when changing accessories such as blades, bits and cutters.
15. **Remove adjusting keys and wrenches**
Form the habit of checking to see that keys and adjusting wrenches are removed from tool before turning it on.
16. **Avoid unintentional starting**
Don't carry plugged-in tool with finger on switch. Be sure switch is off when plugging in.
17. **Outdoor use extension cords**
When tool is used outdoors, use only extension cords intended for use outdoors and so marked.
18. **Stay alert**
Watch what you are doing. Use common sense. Do not operate tool when you are tired.
19. **Check damaged parts**
Before further use of the tool, a guard or other part that is damaged should be carefully checked to determine that it will operate properly and perform its intended function. Check for alignment of moving parts, binding of moving parts, breakage of parts, mounting, and any other conditions that may affect its operation. A guard or other part that is damaged should be properly repaired or replaced by an authorized service center unless otherwise indicated elsewhere in this instructions manual. Have defective switches replaced by an authorized service center. Do not use tool if switch does not turn it on and off.
20. **Warning**
The use of any other accessory or attachment other than recommended in this operating instruction or the Einhell catalog may present a risk of personal injury.
21. **Have your tool repaired by an expert**
This electric appliance is in accordance with the relevant safety rules repairing of electric appliances may be carried out only by experts otherwise it may cause considerable danger for the user.
22. **Connect the dust extraction device**
Wherever there are facilities for fitting a dust extraction system, make sure it is connected and used.

Special safety instructions

- Check that the speed shown on the grinding tool is the same as, or faster than, the rated speed of the grinder.
- Check that the dimensions of the grinding tool match those of the grinder.
- Grinding disks must always be used and stored with care in accordance with the instructions of the manufacturer.
- Always check the grinding disk before use. Never use any disks with pieces broken off, which are cracked or are in any other way damaged.
- Check that grinding tools are attached in accordance with the instructions of the manufacturer.
- Always use backing layers if they are supplied with the grinding tool and their use is specified.
- Check that the grinding tool is properly attached and fastened before use and allow to run without load in a safe position for 30 s. Stop immediately if it should vibrate heavily or if any other fault should become apparent. Examine the machine to find the cause of the fault.
- Never use the electric tool without the guard if a guard is included in delivery.
- Do not use separate reducer sleeves or adapters to make grinding disks with large holes fit properly.
- For grinding tools with threaded inserts, check that the thread is long enough for the length of the spindle.
- Ensure that the tool is securely fastened.
- Take care to ensure that any sparks generated during use do not cause any danger, e.g. by hitting persons or igniting inflammable substances.
- Take care to ensure that the air vents are not blocked whenever you carry out work involving the generation of dust. Should you have to remove any dust, first disconnect the electric tool from the mains power supply (only use non-metallic objects) and avoid any damage to inner parts.
- Use safety goggles and ear-muffs.
- You should also wear protective clothing and equipment such as a dust mask, work gloves, apron and helmet.
- The grinding tool runs on after the tool is switched off.
- The tool may only be used in the open air with extension cables which have been certified as suitable for the purpose. The extension cables used must have cross-sections of least 1.5 mm². The plug-and-socket connections must be

equipped with earthing-contacts and protection against rain-water. Do not use any saw blades.

Always keep these Safety Instructions in a safe place.